



CrossFlight-CE



User Manual for Multirotor

(Compatible with Fixed-wing/Glider/Multirotor/Helicopter/Car/Boat/Robot)

Thank you for purchasing RadioLink flight controller CrossFlight-CE.

To fully enjoy the benefits of this product and ensure safety, please read the manual carefully and set up the device as instructed steps.

If any problems found during the operation process, either way listed below can be used as online tech support.

1. Send mails to after_service@radiolink.com.cn and we will answer your question at the earliest.
2. Send message to us on our Facebook page or leave comments on our YouTube page
3. If the product is purchased from the local distributor, you can also ask them for support and repair as prefer.

All manuals and firmware are available on RadioLink official website www.radiolink.com and more tutorials are uploaded. Or follow our Facebook and YouTube homepage to stay tuned with our latest news.



SAFETY PRECAUTIONS

- Never operate models during adverse weather conditions. Poor visibility can cause disorientation and loss of control of pilots' model.
- Never use this product in a crowd or illegal areas.
- Always check all servos and their connections prior to each run.
- Always be sure about turning off the receiver before the transmitter.
- To ensure the best radio communication, please enjoy the flight/driving at the space without interference such as high voltage cable, communication base station or launching tower.

WARNING

This product is not a toy and is **NOT** suitable for children under the age of 18. Adults should keep the product out of the reach of children and exercise caution when operating this product in the presence of children.

Water or moisture may enter the transmitter inside through gaps in the antenna or joystick and cause model instability, even out of control. If running in the wet weather (such as game) is inevitable, always use plastic bags or waterproof cloth to cover the transmitter.

FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This manual is based on the ARDUPILOT, with setting with RadioLink transmitter AT9S Pro as example. More details about how to use flight controller please refer to:
<http://ardupilot.org/copter/docs/initial-setup.html>

Contents

1. CrossFlight-CE Introduction	5
1.1 Spare Parts	5
1.2 Connectors and Specifications	6
1.3 Advices	8
2. Mission Planner	8
2.1 Install Mission Planner	8
2.2 Mission Planner Introduction	9
3. Initial Setup	10
3.1 Download and Install Firmware	10
3.2 Frame Type	12
3.3 Accelerometer Calibration	13
3.4 Radio Calibration	15
3.5 Compass Calibration	18
3.6 Flight Mode Setup	21
3.7 Flight Mode Introduction	23
3.7.1 Stabilize Mode	23
3.7.2 Acro Mode (FPV)	23
3.7.3 Altitude Hold Mode	24
3.7.4 Auto Mode	25
3.7.5 PosHold Mode	27
3.7.6 RTL Mode	27
3.7.7 Simple and Super Simple Modes	29
3.7.8 More flight modes	31
4. F/S(failsafe) Setting	32
4.1 Radio Failsafe Setup	32
4.2 EKF FailSafe	35
5. Hardware Setup	35
5.1 Install CrossFlight-CE on aircraft	36
5.2 Connect CrossFlight-CE to the aircraft	37
5.2.1 Motor order rotation select	37
5.2.2 How to recognizing clockwise and counterclockwise propellers	39
5.2.3 Connect the Spare Parts	40
5.3 LED Indicator, Arming and Troubleshooting	41

5.3.1 LED Indicator	41
5.3.2 Arming and Disarming	41
5.3.3 Turn off Spinning when Armed	42
5.3.4 Troubleshooting for Arm Failure	43
5.4 ESC Calibration	46
5.5 Level Calibration	46
5.6 GeoFence	47
5.7 Onboard OSD	49
5.7.1 Setting Introduction	49
5.7.2 Screen Introduction	50
6. AutoTune	50
7. Parameter Setting	52
7.1 Parameter Interface Introduction	52
7.2 Parameter Adjustment	53
7.3 Manual Parameter Adjustment	53
8. Download DataFlash Log	53

1. CrossFlight-CE Introduction

1.1 Spare Parts



CrossFlight-CE x1




Power Module
(Support 2-12S)x1



Buzzer x1



I2C Transfer
Board x1



FC Status
Indicate LED x1



Double-sided
Adhesive Tape x2



4G TF (MicroSD)
Card x1



Buzzer&Receiver
Connect Cable x1



TELEM1&2 Ports
Connect Cable x2



FC Status Indicate
LED Cable x1



I2C Transfer Board
Connect Cable x1



OSD Port
Connect Cable x1



I2C Transfer Board
Connect Cable x1



USB Type-C
Cable x1





Quick Start
Guide x1



Packing Box x1

1.2 Connectors and Specifications



Specifications		
Weight & Dimension	Dimension	39.7*39.7*13mm (1.56"*1.56"*0.52")
	Weight	16.5g (0.58oz), 54g (1.9oz when all the connect wires included)
Hardware	Processor	HC32F4A0PITB
Sensor	Gyro & Accelerometer	QMI8658A
	Compass	VCM5883L
	Barometer	SPA06-003
	OSD Chip	AT7456E
	FRAM	Without FRAM, use the internal flash to store parameters, 2617 waypoints for multicopters, and 2623 waypoints for airplanes/cars/boats.
	Buzzer	1
	Safety Switch	None
Connector	Type	JST GH 1.25 Connector
	PWM Output	10 PWM Output
	Mavlink UART	2 (Without CTSRTS)
	USB Port	1 (Type-C)
	GPS UART / I2C Port	1
	Signal Input	PPM/SBUS/CRSF
	RSSI Output	Support
	OSD Module	OSD Module integrated
	ESC Protocol	PWM, DShot, and OneShot Protocol
	RTK	Support
Power Module Specifications	Weight	16.5g (0.58oz) without wire
	Input Voltage	2-12S
	Maximum Detection Current	90A

	Output Voltage (BEC)	5.3V $\pm$ 0.2V
	Output Current (BEC)	2A
	Single ESC Maximum Detection Current	22.5A
Adaptable Models	Airplane/2-8 Copters/Helicopter/Car/Boat/Submarine/Radartracker/Robot	
Operating Parameters	USB Voltage	5V $\pm$ 0.3V
	Servo Voltage	Not applicable
	Operating Temperature	-30~85°C

1.3 Advices

For the users who firstly use CrossFlight-CE, we suggest that you use CrossFlight-CE following below steps:

1. You have to install the mission planner and driver from here and familiar with the menu.
Download the latest Mission Planner from https://www.radiolink.com.cn/crossflightce_missionplanner
Download the driver from <https://www.microsoft.com/net/download/dotnet-framework-runtime/net462>
2. To establish a connection, you must first choose the communication method/channel you want to use, and then set up the physical hardware and Windows device drivers. You can connect the PC and autopilot using USB cables, Telemetry Radios, Bluetooth, IP connections etc.
3. Download the update firmware by USB cable if you need.
4. Connect Mission Planner to AutoPilot, and then connect receiver to AutoPilot to finish the calibration of transmitter, Accelerometer and compass.
5. Setup RC transmitter flight mode.
6. Assemble aircraft and finish the pre-flight checklist.
7. PID usage.
8. Advanced configuration.

2. Mission Planner

2.1 Install Mission Planner

Net Framework 4.6.2 need to be installed first before Mission Planner:

[Download Net Framework 4.6.2 here](#)

Thanks for downloading .NET Framework 4.6.2

Problem downloading? [Try again.](#)



Then you can download Mission Planner for CrossFlight-CE on RadioLink official website:

https://www.radiolink.com.cn/crossflightce_missionplanner

Open the Microsoft installer file and select Run to run the installation utility.



2.2 Mission Planner Introduction

Once installation is complete, open Mission Planner by clicking on its system icon.

Once the installation of Mission Planner and driver is done, there will several pop-ups when you open the MP at the first time. The first pop-up clicks Yes and the others click NO.

There are six Menu Button in main menu.

FLIGHTDATA: flight attitude and data will show in real time on MP.


FLIGHTPLAN: planning the flight mission.

INITIAL SETUP: for firmware installation and update, Mandatory Hardware and Optional Hardware setup.

CONFIG/TUNING: including detailed PID setup and parameters change.

SIMULATION: make CrossFlight-CE work as a simulator after upgrade a special simulation firmware .

HELP: you can get help when you have questions about MP.



3. Initial Setup

- * CrossFlight-CE can only upgrade the firmware from RadioLink.
- * CrossFlight-CE can set parameters by RadioLink Mission Planner, ArduPilot Mission Planner, and QGC Mission Planner.
- * CrossFlight-CE can upgrade the firmware by both RadioLink Mission Planner and ArduPilot Mission Planner (Firmware can only be upgraded by loading custom firmware).

CrossFlight-CE firmware download link: www.radiolink.com.cn/crossflightce_firmware

CrossFlight-CE is default with quadcopter firmware, you have to install the right firmware if you use the other frame drone.


3.1 Download and Install Firmware

Firmware update steps:


Open Mission Planner. Click SETUP--Install Firmware. Connect CrossFlight-CE to the computer via a Type-C cable. Found board appears in the lower-left corner, indicating that the flight controller has been recognized. Click Load custom firmware in the lower-right corner (as shown below) and select the firmware downloaded from RadioLink official website. Follow the prompts to complete the firmware installation and wait for the flight controller firmware to install.

Attention:

- (1) Do not click CONNECT before you upload the new firmware, please click DISCONNECT if you have connected successful before. Upload new firmware will be not success if you have connected already.
- (2) Please do not upload new firmware by wireless data transmission because it has missed the reset signal.



In some situation, it may prompt you to unplug the board, click OK and plug in the board (as shown below). Please disconnect the USB cable, click OK and then reconnect USB cable immediately.




Pay attention: If there are multiple COM port names, connection may fail. Please remove other equipment first.

Red status LED means the CrossFlight-CE is loading the firmware.

After upgrade firmware 3.1 or after version 3.1, there will be a pop-up warning motors will run at idle speed after disarmed.

After it prompts Upload Done, you can click CONNECT in the upper right corner to connect your CrossFlight-CE to Mission Planner and set it.



Pay attention:

- (1) It needs to take a long time to read the parameters.
- (2) There is no option of Load custom firmware in Mission Planner.
- (3) There is no Full Parameter List in INITIAL SETUP.


If you meet the above three problems, please set Layout from “ Basic ” to “ Advanced ” in CONFIG/TUNING menu if any of the three questions as below encountered when you installing the Mission Planner.



3.2 Frame Type


Please setup as below:

1. INITIAL SETUP.
2. Mandatory Hardware—>Frame Type.
3. Choose Quad or Hexa or other frame types as you need.



3.3 Accelerometer Calibration

Make sure the CrossFlight-CE is keeping horizontal when do the accel calibration.



1. Place vehicle level and press any key to save setting.



2. Place vehicle on its LEFT side and press any key to save setting.



3. Place vehicle on its RIGHT side and press any key to save setting.



4. Place vehicle DOWN and press any key to save setting.



5. Place vehicle UP and press any key to save setting.



6. Place vehicle on its BACK and press any key to save setting.



3.4 Radio Calibration

This article shows how to perform radio control calibration in Mission Planner.

RC transmitters are used to control vehicle movement and orientation. Copter and Plane minimally control throttle, pitch, roll and yaw, while on Rover we just control throttle and roll. Each of these control signals are mapped to transmitter stick/switch(s) and in turn to autopilot channels from the connected receiver.

Calibrating each of the transmitter controls/channels is a straightforward process - simply move each of the enabled sticks/switches through their full range and record the maximum and minimum positions.

There are two main transmitter configurations:

Mode 1: left stick controls pitch and yaw, the right stick will control throttle and roll.

Mode 2: left stick controls throttle and yaw; the right stick will control pitch and roll.

Copter default channel mappings are:

Channel 1: Roll

Channel 2: Pitch

Channel 3: Throttle

Channel 4: Yaw

Channel 5: Flight modes

Channel 6: (Optional) In flight tuning or camera mount (mapped to transmitter tuning knob)


Unused channels can be mapped to control additional peripherals.

For safety, you should disconnect the battery and/or remove propellers before performing radio calibration.


Bind your transmitter and receiver before calibrate radio, connect CrossFlight-CE to computer via USB cable and then turn on transmitter. The RC receiver ask to connect to the RC port of CrossFlight-CE.

The transmitter will make AT9S Pro as an example in this manual. Here are the settings on the transmitter:

1. Press Mode button to select MODEL MENU--MODE TYPE and select MULTIROTOR.




2. Setup CH3: THRO REV in REVERSE menu. Press Mode button to select MODEL MENU--REVERSE. Set the throttle channel to REV.





Radio Calibration Steps:

1. Open Mission Planner;
2. Choose the right COM and Baud rate;
3. Click the CONNECT;
4. Choose INITAIL SETUP—Mandatory Hardware—Radio Calibration;
5. Click “Calibrate Radio” .



There are two tool pop-ups after you click “OK” , one for make sure both your transmitter and receiver are powered on and connected, and the motor of your drone does not have power and without propellers.



And then click “OK” and move all RC sticks and switches to their extreme positions so the red bars hit the limits.


If the red bars have not any change when you move the sticks, please check the receiver have connect success or not, make sure the receiver (maybe R9DS) is output SBUS signal (the blue LED of R9DS means work as SBUS signal). You can check if every corresponding red bar for every channel is work as below:

CH1: low position = roll (towards the left), up position= roll (towards the right).


CH2: low position =pitch(forward), up position =pitch(backwards).

CH3: low position =reduced speed, up position =speed up.

CH4: low position = yaw (towards the left), up position = yaw (towards the right).



Click OK to save the radio calibration data.



3.5 Compass Calibration


There are two situations about compass calibration:

1. With external GPS, use external and internal compass at the same time.
2. Without external GPS, use internal compass.

You can also check the video tutorials on how to calibrate the compass:


https://www.youtube.com/watch?v=XR_4e18F5W0

1. When external GPS are used, compass calibrate interface will shows as picture below when use with GPS. Check Compass 1 and Compass 2. Please fixed CrossFlight-CE and GPS, then click “Start” and turn CrossFlight-CE and GPS till the progress bar of Mag 1 and 2 to the end.




Of the two compasses, one is the built-in compass of the flight controller and the other is an external compass (the compass on the GPS). The External option of the external compass will be checked.

If the GPS mounted with the same direction with flight controller, you don't need to set the direction of GPS in MP.




In this picture, the direction of the flight controller and GPS is the same.

If you mount the external GPS with the different direction of CrossFlight-CE, you have to search for COMPASS_ORIENT in Full Parameter List and set the direction of the GPS.




2. When external GPS are used, compass calibrate interface will shows as picture below.




Calibrate the compass as these steps below:


Hold the flight controller in the air and rotate it slowly so that each side (front, back, left, right, top and bottom) points down towards the earth for a few seconds in turn.




Rotate face up




Rotate face down




Rotate left



Rotate right




Turn head up



Turn head down


The mission planner will keep recording the data that collected by the compass sensor and the progress bar and the percentage will keep change when you calibrate the compass, if the percentage have not changed, please check if the compass is connect success.

The mission planner will prompt a notice: Please reboot the autopilot when the compass calibration is successful.



Click OK and then reconnect CrossFlight-CE to computer, compass calibrate success after restart the CrossFlight-CE.

Attention: When the progress bar moves to 100 and then restart from 0, it may because of the wrong calibrate action or interference. You can have a try to calibrate again till compass calibrate success, or setup the Fitness is Relaxed and recalibrate.



3.6 Flight Mode Setup

CrossFlight-CE has multiple flight modes, 6 of which are regularly used. There are modes to support different levels/types of flight stabilization, a sophisticated autopilot, a follow-me system etc. Flight modes are controlled through the radio (via a transmitter switch), via mission commands, or using commands from a ground station (GCS) or companion computer. You can setup six flight modes once and max setup eight modes combine with AUX-CH (CH7 and CH8).

Flight modes setting steps:


1. Connect CrossFlight-CE and receiver (connect the RC port of CrossFlight-CE, and make sure receiver work as SBUS signal).
2. Make sure transmitter bind to receiver success.
3. Make sure CrossFlight-CE connect to Mission Planner success and click INITIAL SETUP—Mandatory Hardware—Flight modes, you can setup the flight modes you want in this menu.

In flight modes menu, it's very clear that the flight modes, the PWM numerical interval of six flight modes you have set and choose Simple Mode/Super Simple Mode or not.


Most of the RC fans setup the Flight Mode 1 is Stabilize, the other five flight mode will be setup according to users' flight habit.

First, you have to setup flight mode in transmitter. The setting steps as below:

1. Power on and turn on your transmitter.
2. Press Mode button twice to into ADVANCE MENU, press Push button into ATTITUDE setting menu, CH5 is default to the attitude control channel and please choose a 3 Posi-SW and a 2 Posi-SW to control the attitude. (For the flight mode settings of CH7 and CH8, open Mission Planner---configuration/debugging---extended parameters---Channel 7 opt/Channel 8 opt, and then assign 2 control switches for the two channels in the transmitter.)



3. Setup Flight Mode 1 is Stabilize both in Mission Planner and transmitter. Make sure the -swt- is ON (by press the 3 Posi-SW or 2 Posi-SW to make it ON or OFF) and then you can setup the PWM data. Setup the PWM value according to the default numerical interval (change the value by turn the dial, press the Push button when you choose the right value.)
4. Mode 4 needs a two-way switch. Turn the switch to the corresponding mode. Set it in the same way as step 3.
5. Please check the introduction of simple mode and super simple mode, and then you can choose whether to start simple mode or super simple mode in the mode.



3.7 Flight Mode Introduction

3.7.1 Stabilize Mode

Stabilize mode allows you to fly your vehicle manually, but self-levels the roll and pitch axis.

If you're learning to fly, try Alt Hold or Loiter instead of Stabilize. You'll have fewer crashes if you don't need to concentrate on too many controls at once.

- (1) Pilot's roll and pitch input control the lean angle of the copter. When the pilot releases the roll and pitch sticks the vehicle automatically levels itself.
- (2) Pilot will need to regularly input roll and pitch commands to keep the vehicle in place as it is pushed around by the wind.
- (3) Pilot's yaw input controls the rate of change of the heading. When the pilot releases the yaw stick the vehicle will maintain its current heading.
- (4) Pilot's throttle input controls the average motor speed meaning that constant adjustment of the throttle is required to maintain altitude. If the pilot puts the throttle completely down the motors will go to their minimum rate (MOT_SPIN_ARMED) and if the vehicle is flying it will lose attitude control and tumble.
- (5) The throttle sent to the motors is automatically adjusted based on the tilt angle of the vehicle (i.e. increased as the vehicle tilts over more) to reduce the compensation the pilot must do as the vehicle's attitude changes.

Always switch into a manual mode such as stabilize if the autopilot fails to control the vehicle. Maintaining control of your copter is your responsibility.

3.7.2 Acro Mode (FPV)

Acro mode (Rate mode) uses the RC sticks to control the angular velocity of the copter. Release the sticks and the vehicle will maintain its current attitude and will not return to level. Acro mode is useful for aerobatics such as flips or rolls, or FPV when smooth and fast control is desired.

ACRO mode trainer


ACRO_TRAINER setting

- 0 is disabled. This means the pilot operates in full Rate control with no automatic leveling nor angle-limiting performed by the autopilot.

- 1 is automatic leveling. The vehicle will automatically return to the level when the pilot releases the sticks. The aggressiveness with which it returns to level can be controlled with the ACRO_BAL_ROLL and ACRO_BAL_PITCH parameters. The default of 1.0 will cause it to return to level at up to 30deg/sec. Higher values will make it return more quickly.

- 2 is Default to automatic leveling and lean angle limited. Includes the automatic leveling as option #1 but in addition the vehicle will not lean more than 45 degrees (this angle can be configured with the ANGLE_MAX parameter).

The trainer can be enabled/disabled using the Ch7/Ch8 switches. With a 3 position switch the off position (i.e. PWM < 1200) will disable the trainer, middle position will enable option #1 (automatic leveling) and the top position (i.e. PWM > 1800) will enable option #2 (leveling and lean angle limited). With a 2-position switch only options #0 (disabled) and option #2 (leveling & limited) are possible.



Parameters Setting:

ACRO_RP_RATE controls the rotation rate of the roll and pitch axes, by default 360, which represents a rotation rate of 360 degrees/second. Higher values result in higher spin rates, lower values result in lower spin rates.

ACRO_Y_RATE controls the rotation speed of the yaw axis. By default 202.5, like roll and pitch, represents a rotation rate of 202.5 degrees/second.


ACRO_RP_EXPO Acro roll/pitch Expo to allow faster rotation when stick at edges.

ACRO_Y_EXPO Acro yaw expo to allow faster rotation when stick at edges.

3.7.3 Altitude Hold Mode

In altitude hold mode, Copter maintains a consistent altitude while allowing roll, pitch, and yaw to be controlled normally. This page contains important information about using and tuning AltHold.

Automatic altitude hold is a feature of many other flight modes (Loiter, Sport, etc.) so the information here pertains to those modes as well.



Note: The flight controller uses a barometer which measures air pressure as the primary means for determining altitude (“Pressure Altitude”) and if the air pressure is changing in your flight area due to extreme weather, the copter will follow the air pressure change rather than actual altitude. When fitted and enabled, a downward facing rangefinder such as LiDAR or SONAR will automatically provide even more accurate altitude maintenance, up to the limit of the sensor.

How to control

The pilot can control the climb or descent rate of the vehicle with the throttle stick. If the throttle stick is in the middle (40% ~ 60%) the vehicle will maintain the current altitude. Outside of the mid-throttle deadzone (i.e. below 40% or above 60%) the vehicle will descend or climb depending upon the deflection of the stick. When the stick is completely down the copter will descend at 2.5m/s and if at the very top it will climb by 2.5m/s. These speeds can be adjusted with the PILOT_SPEED_UP and PILOT_SPEED_DN parameters.


The size of the deadband can be adjusted with the THR_DZ parameter (AC3.2 and higher only). This param's value should be between “0” and “400” with “0” meaning no deadband. “100” would produce a deadband 10% above and below mid throttle (i.e. deadband extends from 40% to 60% throttle stick position).

AC3.1 and later allow arming and disarming in altitude hold mode. When disarming, the copter may need to rest in the landing position for a few seconds to allow the “landing checker” to verify that the copter has landed before you are able to disarm.

3.7.4 Auto Mode

In Auto mode the copter will follow a pre-programmed mission script stored in the autopilot which is made up of navigation commands (i.e. way points) and “do” commands (i.e. commands that do not affect the location of the copter including triggering a camera shutter). CrossFlight-CE multi-rotor firmware can store up to 2617 waypoints, commands and events at one time.

AUTO



AUTO mode incorporates the altitude control from AltHold mode and position control from Loiter mode and should not be attempted before these modes are flying well. All the same requirements apply including ensuring that vibration levels and compass interference levels are acceptable and that the GPS is functioning well including returning an HDOP of under 2.0.

AUTO should be set-up as one of the Flight Modes on the flight mode switch.

Make sure that the GPS is positioning first:

- The LED of CrossFlight-CE is green.
- The LED of GPS and compass module is blinking.

If starting the mission while the copter is on the ground the pilot should ensure the throttle is down, then switch to the Auto flight mode, then raise the throttle. The moment that the throttle is raised above zero, the copter will begin the mission.

If starting the mission from the air the mission will begin from the first command the moment that the flight mode switch is moved to Auto. If the first command in the mission is a take-off command but the vehicle is already above the take-off command's altitude the take-off command will be considered completed and the vehicle will move onto the next waypoint.

At any time, the pilot can retake control from the autopilot by returning the flight mode switch to another flight mode such as Stabilize or Loiter. If the pilot then switches to AUTO again, the mission will restart from the first command.

During the mission the pilot's roll, pitch and throttle inputs are ignored but the yaw can be overridden with the yaw stick. This allows the pilot to for example aim the nose of the copter (which might have a

hard-mounted camera on it) as the copter flies the mission. The autopilot will attempt to retake yaw control as the vehicle passes the next waypoint.

Ending a mission

Missions should normally have an RTL as their final command to ensure the copter will return after the mission completes. Alternatively, the final command could be a LAND with a different location. Without

a final RTL or LAND command the copter will simply stop at the final waypoint and the pilot will need to retake control with the transmitter.

Remember that when using RTL, the copter will return to the “home” position which is the location where the copter was armed.

As the copter touches down at the end of the mission the pilot should move the throttle to zero at which point the autopilot will disarm the motors if it also believes that it has landed.

3.7.5 PosHold Mode

The PosHold flight mode (previously known as “Hybrid”) is a new mode for AC3.2. It is similar to Loiter in that the vehicle maintains a constant location, heading, and altitude but is generally more popular because the pilot stick inputs directly control the vehicle’ s lean angle providing a more “natural” feel.

When switched on, PosHold mode will automatically attempts to maintain the current location, heading and altitude. Good GPS position, low magnetic interference on the compass and low vibrations are all important in achieving good loiter performance.

How to control

The pilot can control the copter’ s location horizontally and vertically with the control sticks.

Horizontal location can be adjusted with the Roll and Pitch control sticks with the default maximum lean angle being 45 degrees (angle can be adjusted with the ANGLE_MAX parameter). When the pilot releases the sticks, the copter will lean back to bring the vehicle to a stop.

Altitude can be controlled with the Throttle control stick just as in AltHold mode.

The heading can be set with the Yaw control stick.

You may arm in PosHold mode but only once the GPS has 3D lock and the HDOP has dropped to 2.0 or lower.

The HDOP value can be made clearly visible through the mission planner’ s Quick screen by double clicking and then selecting “gpshdop” from the large grid of checkboxes.

The maximum brake-angle can be set with the PHLD_BRAKE_ANGLE parameter (i.e. 3000 = the vehicle will lean back up to 30degrees).


The speed the vehicle rotates back to the maximum angle can be set with the PHLD_BRAKE_RATE parameter (i.e. 8 = rotates back at 8 degrees per second)).

3.7.6 RTL Mode

This very simple flight mode simply stops the vehicle as soon as possible using the Loiter controller. Once invoked, this mode does not accept any input from the pilot. This mode requires GPS.

RTL mode (Return to Launch mode) navigates Copter from its current position to hover above the home position. The behavior of RTL mode can be controlled by several adjustable parameters.

When RTL mode is selected, the copter will return to the home location. The copter will first rise to RTL_ALT before returning home or maintain the current altitude if the current altitude is higher than RTL_ALT. The default value for RTL_ALT is 15m.



RTL is a GPS-dependent move, so it is essential that GPS lock is acquired before attempting to use this mode. Before arming, ensure that the APM's blue LED is solid and not blinking. For a GPS without compass, the LED will be solid blue when GPS lock is acquired. For the GPS+Compass module, the LED will be blinking blue when GPS is locked.

RTL will command the copter to return to the home position, meaning that it will return to the location where it was armed. Therefore, the home position is always supposed to be your copter's actual GPS takeoff location, unobstructed and away from people. For Copter if you get GPS lock and then ARM your copter, the home position is the location the copter was in when it was armed. This means if you execute an RTL in Copter, it will return to the location where it was armed.

In RTL mode the flight controller uses a barometer which measures air pressure as the primary means for determining altitude ("Pressure Altitude") and if the air pressure is changing in your flight area, the copter will follow the air pressure change rather than actual altitude (unless you are within 20 feet of the ground and have SONAR installed and enabled).

Options (User Adjustable Parameters)

1. RTL_ALT: The minimum altitude the copter will move to before returning to launch.
 - (1) Set to zero to return at the current altitude.
 - (2) The return altitude can be set from 1 to 8000 centimeters.
 - (3) The default return altitude Default is 15 meters (1500).
2. RTL_ALT_FINAL: The altitude the copter will move to at the final stage of "Returning to Launch" or after completing a Mission.
 - (1) Set to zero to automatically land the copter.
 - (2) The final return altitude may be adjusted from 0 to 1000 centimeters.
3. RTL_LOIT_TIME: Time in milliseconds to hover/pause above the "Home" position before beginning final descent.

The "Loiter" time may be adjusted from 0 to 60,000 milliseconds.
4. WP_YAW_BEHAVIOR: Sets how the autopilot controls the "Yaw" during Missions and RTL.
 - (1) 0 = Never change Yaw.
 - (2) 1 = Face Next Waypoint including facing home during RTL.

(3) 2 = Face Next Waypoint except for RTL (i.e. during RTL vehicle will remain pointed at its last heading).

5. LAND_SPEED: The descent speed for the final stage of landing in centimeters per second.

The landing speed is adjustable from 20 to 200 centimeters per second.

6. RTL_CLIMB_MIN: The vehicle will climb at least these many meters at the first stage of the RTL. By default, this value is zero. (only Copter-3.3 and above)

7. RTL_SPEED: The horizontal speed (in cm/s) at which the vehicle will return to home. By default, this value is zero meaning it will use WPNAV_SPEED (Only Copter-3.4 and higher).

8. RTL_CONE_SLOPE: Defines the slope of an inverted cone above home which is used to limit the amount the vehicle climbs when RTL-ing from close to home. Low values lead to a wide cone meaning the vehicle will climb less, High values will lead to the vehicle climbing more (Supported in Copter-3.4 and higher).

Notes:

1. Other navigation settings also have an influence over RTL mode:

(1) WPNAV_ACCEL

(2) WPNAV_SPEED_DN

(3) WPNAV_SPEED_UP

2. To use RTL, GPS lock needs to be achieved (Blue GPS LED and Blue APM LED on solid not blinking) before arming and takeoff to establish the home or launch position.

3. Landing and re-arming the copter will reset home, which is a great feature for flying at airfields.

4. If you get lock for the first time while flying, your home will be set at the location of lock.

5. If you set the RTL_ALT to a number at other than 0 it will go to and maintain that altitude while returning.

6. RTL uses WPNAV_SPEED to determine how fast it travels.

7. Once the copter arrives at the home location the copter will pause for RTL_LOIT_TIME milliseconds, timeout (AUTO_LAND), then land.

3.7.7 Simple and Super Simple Modes

“Simple” and “Super Simple” modes allow the pilot to control the movement of the copter from the pilot’s point of view regardless of which way the copter is facing. This is useful for new pilots who have not mastered adjusting their roll and pitch inputs depending upon which way the vehicle is facing and for cases when the copter is far enough away that its heading is not apparent.


(1) “Simple” and “Super Simple” modes can be used in combination with nearly all flight modes except the Acro and Drift (in these flight modes the setting is ignored).

(2) Simple Mode allows you to control the copter relative to the copters heading at takeoff and relies only on a good compass heading.

(3) Super Simple Mode allows you to control the copter relative to its direction from home (i.e. where it was armed) but requires a good GPS position.

(4) Either mode can be assigned to a particular flight mode switch position or can be enabled/disabled from the Ch7/Ch8 switches.


Normal Mode



Without Simple or Super Simple enabled, the pilot's transmitter stick inputs are applied in the orientation of the copter. For example, in the diagram above when the pilot applies roll input right (red) the vehicle rolls to its right.

With the copter is facing in the same direction as the pilot, it is relatively easy to control the vehicle but when the vehicle is facing towards the pilot an inexperienced pilot will feel that the controls are all reversed. I.e. if the pilot inputs right roll, the vehicle will move to the left from the pilot's point of view.

Simple Modes




Similar to the "care free" mode on other systems, this mode allows you to fly your copter as though it were pointed in the direction it was pointed when it was armed regardless of its current heading orientation. So, if you hold the pitch stick forward the copter will fly away from you, pull the pitch stick back and it will come back towards home. You can even apply yaw to spin the copter in any direction

but the movement of the copter' s position relative to the stick inputs will behave exactly as it did at takeoff.

Generally, when arming you should stand behind the vehicle with its nose pointing directly away from you. While flying you should try to keep the vehicle flying in front of its starting position because if it flies behind you all the controls will feel reversed.

As mentioned above simple mode is also very useful in emergency situations where the copter is far enough away that it is very difficult to determine its heading.

Super Simple Modes



Super Simple mode is the same as simple mode except that it uses the vehicle' s position relative to home instead of the vehicle' s initial heading when it was armed. This means that no matter where the vehicle is, pulling the pitch back will cause it to return towards home regardless of the vehicle' s actual heading.

The advantage over simple mode is that the controls are applied from the pilot' s point of view even when the copter flies behind the pilot/home location.

If the pilot holds full right roll the vehicle will fly a circle clockwise around the pilot (although the circle' s radius may tend to grow slightly with each orbit due to "lag").

The disadvantage is that mode require a GPS lock because so you should ensure you have GPS lock before take-off.

The orientation is not updated when the vehicle is within 10m of home meaning close fly-bys of the home location should be avoided.

To ensure the controls are correct right at take-off, as with simple mode, you should arm with the pilot standing behind the vehicle and with both pilot and vehicle pointing in the same direction.

3.7.8 More flight modes

Guided Mode: Guided mode is a capability of Copter to dynamically guide the copter to a target location wirelessly using a telemetry radio module and ground station application. This page provides instructions for using guided mode.

Loiter Mode: Loiter Mode automatically attempts to maintain the current location, heading and altitude. The pilot may fly the copter in Loiter mode as if it were in a more manual flight mode but when the sticks are released, the vehicle will slow to a stop and hold position.

Circle Mode: Circle will orbit a point located CIRCLE_RADIUS centimeters in front of the vehicle with the nose of the vehicle pointed at the center.

Drift Mode: This page provides tips for flying in Drift Mode and methods for tuning your copter to fly optimally in Drift Mode.

Sport Mode: Sport Mode is also known as “rate controlled stabilize” plus Altitude Hold.

Flip Mode: Vehicle will flip on its roll or pitch axis depending upon the pilot’s roll and pitch stick position. Vehicle will rise for 1 second and then rapidly flip. The vehicle will not flip again until the switch is brought low and back to high. Give yourself at least 10m of altitude before trying flip for the first time!

AutoTune: AutoTune attempts to automatically tune the Stabilize P, Rate P and D, and maximum rotational accelerations to provide the highest response without significant overshoot. Copter needs to be “basically” flyable in AltHold mode before attempting to use AutoTune as the feature needs to be able to “twitch” the copter in the roll and pitch axis.

Land Mode: LAND Mode attempts to bring the copter straight down.

Break Mode: This very simple flight mode simply stops the vehicle as soon as possible using the Loiter controller. Once invoked, this mode does not accept any input from the pilot. This mode requires GPS.

Throw Mode: This slightly dangerous flight mode allows the pilot to throw the vehicle into the air (or drop the vehicle) in order to start the motors. Once in the air, this mode does not accept any input from the pilot. This mode requires GPS.

Avoid_ADSB: for ADS-B based avoidance of manned aircraft. Should not be set-up as a pilot selectable flight mode.

Guided_NoGPS: which is meant for developer use only.

The detailed introduction about more flight modes, please check on website here:

<http://ardupilot.org/copter/docs/flight-modes.html>

<http://www.ncnynl.com/archives/201608/417.htmlk>


4. F/S(failsafe) Setting

4.1 Radio Failsafe Setup

CrossFlight-CE supports Return-To-Launch in cases where contact between the Pilot’s RC transmitter and the flight controller’s receiver is lost. This page explains this failsafe’s setup and testing. Note the “Radio failsafe” was previously called “Throttle failsafe” because of the way in which some receivers use the throttle channel to signal the loss of contact.

F/S setting steps:

Setup in transmitter: setup the throttle trim to -120 by trim switch and then press Mode button one second into BASIC MENU, choose and into F/S menu, put the throttle stick to the bottom to setup 3: THRO 3%. Please setup the throttle trim back to 0 after setup the THRO 3% success.



Receiver and flight controller CrossFlight-CE setup:

By default, a newly purchased receiver will be set-up to simply hold all channels at their last known position when the receiver and transmitter lose contact. This is not good because the flight controller has no way to know that the Pilot has lost control of the vehicle. Instead the receiver must be set-up to signal to the flight controller it has lost contact and there are two ways that it can do this (the method depends upon the receiver):


“Low-Throttle” method - the receiver pulls the throttle channel (normally channel 3) to a value below the bottom of its normal range (normally below 975).

With the LiPo battery disconnected:


1. Connect your flight controller to the mission planner and select Initial Setup >> Mandatory Hardware >> Failsafe.
2. Set the Failsafe Options to one of the three options:
 - (1) “Enabled always RTL” to force the vehicle to always RTL even if flying a mission in AUTO mode.
 - (2) “Enabled Continue with Mission in AUTO” to allow the vehicle to continue with missions even if it takes the vehicle outside of RC range (not recommended). In all other cases the vehicle will RTL.
 - (3) “Enable always LAND” to force the vehicle to Land immediately if it loses RC contact.

Set the “FS PWM” value to be:

- (1) at least 10 PWM higher than your Channel 3’ s PWM value when the throttle stick is fully down and the transmitter is off.
- (2) at least 10 lower than your channel 3’ s PWM value when the throttle stick is fully down and the transmitter is on.
- (3) above 910.



Click OK to into the failsafe setting menu.



You can turn off transmitter to check if the Failsafe function setup success(the PWM of CH3 is smaller than 975).

If enabled and set-up correctly the radio Failsafe will trigger if:

- (1) The pilot turns off the RC transmitter.
- (2) The vehicle travels outside of RC range.
- (3) The receiver loses power (unlikely).
- (4) The wires connecting the receiver to the flight controller are broken (unlikely).

1. Set battery fail safe

Set battery fail safe according to the aircraft power consumption, battery voltage, and flight distance. When the battery voltage is lower than this value, there will be enough battery voltage to return the aircraft. Set the low battery value (This value is set according to the battery voltage. When you fly long distances, Please set the single cell to 3.8V, the voltage value is $3.8V \times S$, the 3S battery is $3.8 \times 3 = 11.4V$; when at a close distance, you can set 3.6V for each cell), and set the action to RTL (return to home).

2. Set the radio fail safe (throttle fail safe) . Set the action to RTL , and set the fail safe PWM (generally no need to change). Set the fail-safe setting in the transmitter, because we set the fail safe to start after the throttle is lower than 975, so we need to set the throttle fail safe value. Push the throttle trim button in the transmitter and check the input value of channel 3 in the transmitter in fail safe, so that the value is less than 10 or more than 975. Take RadioLink AT9S Pro as an example. Press the Mode button to enter the basic menu and select FAIL SAFE. Press Push to select Channel 3: Throttle. Turn the dial to select F/S and press Push button. When a value appears, the setting is successful. Remember to turn trim button to restore.

When a radio Failsafe is triggered one of the following will happen:

- Nothing if the vehicle is already disarmed.
- Motors will be immediately disarmed if the vehicle is landed OR in stabilize or acro mode and the pilot's throttle is at zero.
- Return-to-Launch (RTL) if the vehicle has a GPS lock and is more than 2 meters from the home position.
- LAND if the vehicle has no GPS lock OR is within 2 meters of home OR the FS_THR_ENABLE parameter is set to "Enabled Always Land" .
- Continue the task if in automatic mode and the failsafe option is Enabled_continue_in_auto_mode.

- If the failsafe is cleared (the throttle is above 975), the aircraft will continue to fly in the flight mode corresponding to the previously set failsafe, and will not automatically return to the previous flight mode of normal flight.

For example: the RTL mode is set for the fail safe, and the aircraft is flying normally in stabilize mode. Suddenly the fail safe is triggered due to signal loss, causing the aircraft's flight mode to automatically change from the stabilize mode to the previously set RTL mode. Even if the transmitter and receiver signals are reconnected during the return journey and the fail safe is released, the aircraft will still fly in the RTL mode. If you need to fly in stabilize mode again, you need to move the flight mode switch to another position and then back to the position of stabilize mode.

3. Set attitude fail safe in the transmitter. **The prerequisite for setting attitude fail safe is that there is a fail safe mode in the flight mode settings.** Taking RadioLink AT9S Pro as an example. Turn on the transmitter, flip the setting switch to RTL mode or the fail-safe mode you want to set, press Mode to enter the MODEL MENU--FAIL SAFE. press Push to select 5: Attitude, Toggle to select F/S, hold Push, and the numbers below will change. Open Mission Planner to verify it. Turn off the transmitter and check that it is RTL in Mission Planner.

4.2 EKF FailSafe

FS_EKF_ACTION

Note: This parameter is for advanced users.

Controls the action that will be taken when an EKF failsafe is invoked.

Values	
Value	Meaning
1	Land
2	AltHold
3	Land even in Stabilize

It defaults the value 1, that is the drone will land if lose signal, but you can change the setting from value 1 to value 2, which means the drone will AltHold if lose signal.

FS_EKF_THRESH

Note: This parameter is for advanced users.

Allows setting the maximum acceptable compass and velocity variance.

Values
0.6:Strict, 0.8:Default, 1.0:Relaxed

5. Hardware Setup


Prepare a drone first, a X frame quadcopter as a sample, please mount a CrossFlight-CE as below steps after you have assembled the drone.

1. Mount a CrossFlight-CE on the center position of the drone, and make sure that the CrossFlight-CE is horizontal on the drone.

2. Connect the Mission Planner after download the firmware, calibrate and setup parameters as the steps above.
3. Arm it. If the arm can be done, fly the aircraft after installing the propellers; if arm can be done, find the problem of setting or calibration and solve it.
4. To calibrate the ESC (first flight), please remove the propellers.

5.1 Install CrossFlight-CE on aircraft

Mount the CrossFlight-CE at the barycenter of the drone, make sure the arrow of the CrossFlight-CE is point to the front.



Keep the GPS with the same direction of CrossFlight-CE if you need to use CrossFlight-CE with GPS.

If the installation can't be done with the default direction, parameters need to be setup according to the installation direction.

AHRS_ORIENTATION

AHRS_ORIENTATION	0	0:None 1:Yaw45 2:Yaw90 3:Yaw135 4:Yaw180 5:Yaw225 6:Yaw270 7:Yaw315 8:Roll0 9:Roll90 10:Yaw45 11:Roll0 12:Yaw90 13:Roll180 14:Yaw135 15:Roll180 16:Roll180 17:Yaw225 18:Roll180 19:Yaw270 20:Roll180 21:Yaw315 22:Roll180 23:Roll0 24:Yaw45 25:Roll180 26:Yaw90 27:Roll90 28:Yaw135 29:Roll270 30:Roll270 31:Yaw180 32:Roll270 33:Yaw135 34:Roll90 35:Pitch270 36:Pitch90 37:Yaw90 38:Roll90 39:Pitch90 40:Roll180 41:Pitch90 42:Roll270 43:Pitch180 44:Roll90 45:Pitch270 46:Roll180 47:Pitch270 48:Roll90 49:Pitch180 50:Yaw90 51:Roll90 52:Yaw270	Overall board orientation relative to the standard orientation for the board type. This rotates the IMU and compass readings to allow the board to be oriented in your vehicle at any 90 or 45 degree angle. This option takes effect on next boot. Also changing you will need to relevel your vehicle.
------------------	---	---	--

Set the rotation direction and degree and the corresponding values basing on the variation of the flight controller and the aircraft vehicle and input to save. Restart and test if the movements of the flight controller are correct at the homepage of Mission Planner.

5.2 Connect CrossFlight-CE to the aircraft

5.2.1 Motor order rotation select




Green means CW

Blue means CCW





Legend for motor-order diagrams

Quadcopters



Hexacopter



Octocopter




OCTO +




OCTO X

Y6




New Y6
Y6B




Old Y6
Y6A

X8



X8
(OCTA QUAD)


Tricopter



Note Since there' s no voltage output from the flight controller, an extra BEC module needs to be connected to power supply servo for this model frame .

5.2.2 How to recognizing clockwise and counterclockwise propellers

There are clockwise propellers and counterclockwise propellers. The high side of the propeller points in the direction of rotation. The propeller that rotate clockwise are CW propellers, and the propeller that rotate counterclockwise are CCW propellers.



CCW propellers (counterclockwise rotation)



CW propellers (clockwise rotation)


5.2.3 Connect the Spare Parts

Receiver module and buzzer: connect to the flight control RC IN/BUZZER port with the provided 5pin GH plug-in cable.

Power Module: use a 6-pin GH wire to connect the power module to the POWER port of the CrossFlight-CE.

GPS and compass: use a 6-pin GH wire to connect the GPS (TS100 for example) to the GPS/I2C port of the CrossFlight-CE, please make sure that GPS keeps the same direction as CrossFlight-CE.

Battery Monitor Setup



Mission Planner Setup

Battery measurement is primarily set up in **SETUP -- Optional Hardware -- Battery Monitor** screen.

Enter the properties your module can measure, the type of module, the type of flight controller, and the battery capacity:

Monitor: Voltage and Current or Battery Volts.

Sensor: Supported power module, or “Other” .

APM ver: Flight controller (e.g. Pixhawk).

Battery Capacity: Battery capacity in mAh.

When the setting is turned on, please disconnect the flight controller, power on the flight controller again, then open this interface and enter the measured battery voltage. When the voltage that appears in the 2 battery voltage (calculated) box is the same as the entered measurement value and no longer jumps, it means the setting is normal.

Note: When the setting is inaccurate, it may be impossible to arm, or the buzzer may beep quickly after arming. This means that the power supply is not set incorrectly. Please set it correctly again. If there is a continuous fail safe situation, it is possible that the battery low-voltage fail safe is turned on and the battery monitoring is inaccurate.

5.3 LED Indicator, Arming and Troubleshooting

5.3.1 LED Indicator

	Blue and red flashing: Initializing.
	Yellow flashing twice: Error, Arming rejected.
	Blue flashing: Stabilize, can be armed. Fail to RTL or PosHold.
	Green flashing: GPS locked, can be armed and take off, RTL.
	Green always on + a long D sound: Armed and ready to take off.
	Yellow flashing: Transmitter failsafe activated.
	Yellow flashing+repeated sounds: Battery failsafe activated.
	Yellow flashing+High/High/Low sounds: GPS data error or GPS failsafe activated.

5.3.2 Arming and Disarming

When your the LED of the flight controller is blue or green, you can arm it. When the LED is yellow, you can also perform arming and check the cause of the fault.

Arm action:


1. Use the left joystick to perform the arm action shown below (The stick mode is mode 2):



2. Hold it for 5 seconds;
3. When you hear the buzzer beeping for a long time and the flight controller indicator light is always on, the arming is successful.

Note:

1. When the stick mode of the transmitter is not mode 2, please make sure Channel 3 is at the lowest and channel 4 is at the highest to perform arming. You can check the action in Mission Planner.



In the above picture, Channel 3 is at the lowest and channel 4 is at the highest.

2. If the buzzer beeps when the arming action is performed, the arming fails. Please connect the flight controller to Mission Planner to check the disarm prompt, and solve the fault according to the fault instructions in the next chapter.

Disarm action:

Hold the left joystick to perform the arm action shown below for 5 seconds. (The stick mode is mode 2). When the LED of flight controller flashes and propellers stop rotating, the disarming is successful.



Note:


1. When the stick mode of the transmitter is not mode 2, please make sure Channel 3 is at the lowest and channel 4 is at the lowest to perform disarming.
2. In GPS-assisted mode such as Alt-Hold mode, PosHold mode and Loiter mode, please wait for the propeller to stop before performing the disarming action, otherwise the aircraft may flip over.

5.3.3 Turn off Spinning when Armed

If you connect the battery and armed, the motors begin to have speed even though the throttle is at zero. It reminds you that CrossFlight-CE is in service and please take care of the safety. This function is very importance for the safety but if you do not want use this function, you can turn off it.

How to turn off this function:

Setup the number of Spin when Armed from 0.100 to 0.000 as the picture below.



5.3.4 Troubleshooting for Arm Failure


Pre-Arm Safety Checks:

1. Radio calibrated
2. Accelerometers calibrated
3. Compass healthy
4. Compass offsets
5. Compass calibrated
6. Compass Field length
7. Barometer healthy
8. Geofencing & GPS lock
9. Board Voltage

For more details of Pre-arm safety check, please refer to the link:

<https://ardupilot.org/copter/docs/common-prearm-safety-checks.html>

When the arming fails, the flight controller LED indicator flashes yellow, perform arming action, and the buzzer prompts. Connect the flight controller to Mission Planner to view the fault prompt. After connecting, view the following interface:



When a prompt starting with PreArm appears in red font, this represents the cause of the fault at this time. For details, you can check the translation and comparison of the prompts below to solve them;
When there is no red font displayed, you can perform the arming action, which will be displayed, or view the top line of text in the message bar;
After solving the fault, power on the flight controller again. After the flight control starts normally, the status indicator light will turn blue and flash, which means it can be armed;

Some failure messages:

safe switch: The safety switch is not closed. Check the value of BRD_SAFETYENABLE in all parameter list. If it is 1, modify it to 0.

RC not calibrated: the radio calibration has not been performed. RC3_MIN and RC3_MAX must have been changed from their default values (1100 and 1900), and for channels 1 to 4, MIN value must be 1300 or less, and MAX value 1700 or more.

Barometer failures:

Baro not healthy: the barometer sensor is reporting that it is unhealthy which is normally a sign of a hardware failure.

Alt disparity: the barometer altitude disagrees with the inertial navigation (i.e. Baro + Accelerometer) altitude estimate by more than 2 meters. This message is normally short-lived and can occur when the flight controller is first plugged in or if it receives a hard jolt (i.e. dropped suddenly). If it does not clear the accelerometers may need to be calibrated or there may be a barometer hardware issue.

Compass failures:

Compass not healthy: the compass sensor is reporting that it is unhealthy which is a sign of a hardware failure.

Compass not calibrated : the compass(es) has not been calibrated. the COMPASS_OFS_X, Y, Z parameters are zero or the number or type of compasses connected has been changed since the last compass calibration was performed.

Compass offsets too high: the primary compass' s offsets length (i.e. $\sqrt{x^2+y^2+z^2}$) are larger than 500. This can be caused by metal objects being placed too close to the compass. If only an internal compass is being used (not recommended), it may simply be the metal in the board that is causing the large offsets and this may not actually be a problem in which case you may wish to disable the compass check.

Check mag field: the sensed magnetic field in the area is 35% higher or lower than the expected value. The expected length is 530 so it' s > 874 or < 185 . Magnetic field strength varies around the world but these wide limits mean it' s more likely the compass calibration has not calculated good offsets and should be repeated.

Compasses inconsistent: the internal and external compasses are pointing in different directions (off by >45 degrees). This is normally caused by the external compasses orientation (i.e. COMPASS_ORIENT parameter) being set incorrectly.

GPS related failures:

GPS Glitch : the GPS is glitching and the vehicle is in a flight mode that requires GPS (i.e. Loiter, PosHold, etc) and/or the circular fence is enabled.

Need 3D Fix : the GPS does not have a 3D fix and the vehicle is in a flight mode that requires the GPS and/or the circular fence is enabled.

Bad Velocity: the vehicle' s velocity (according to inertial navigation system) is above 50cm/s. Issues that could lead to this include the vehicle actually moving or being dropped, bad accelerometer calibration, GPS updating at below the expected 5hz.

High GPS HDOP : the GPS' s HDOP value (a measure of the position accuracy) is above 2.0 and the vehicle is in a flight mode that requires GPS and/or the circular fence is enabled. This may be resolved by simply waiting a few minutes, moving to a location with a better view of the sky or checking sources of GPS interference (i.e. FPV equipment) are moved further from the GPS. Alternatively, the check can be relaxed by increasing the GPS_HDOP_GOOD parameter to 2.2 or 2.5. Worst case the pilot may disable the fence and take-off in a mode that does not require the GPS (i.e. Stabilize, AltHold) and switch into Loiter after arming but this is not recommended.

Note: the GPS HDOP can be readily viewed through the Mission Planner' s Quick tab as shown below.

INS checks (i.e. Accelerometer and Gyro checks):

INS not calibrated: some or all of the accelerometer' s offsets are zero. The accelerometers need to be calibrated.

Accels not healthy: one of the accelerometers is reporting it is not healthy which could be a hardware issue. This can also occur immediately after a firmware update before the board has been restarted.

Accels inconsistent: the accelerometers are reporting accelerations which are different by at least 1m/s/s. The accelerometers need to be re-calibrated or there is a hardware issue.

Gyros not healthy: one of the gyroscopes is reporting it is unhealthy which is likely a hardware issue. This can also occur immediately after a firmware update before the board has been restarted.

Gyro cal failed: the gyro calibration failed to capture offsets. This is most often caused by the vehicle being moved during the gyro calibration (when red and blue lights are flashing) in which case unplugging the battery and plugging it in again while being careful not to jostle the vehicle will likely resolve the issue. Sensors hardware failures (i.e. spikes) can also cause this failure.

Gyros inconsistent: two gyroscopes are reporting vehicle rotation rates that differ by more than 20deg/sec. This is likely a hardware failure or caused by a bad gyro calibration.

Board Voltage checks:

Check Board Voltage: the board' s internal voltage is below 4.3 Volts or above 5.8 Volts.

If powered through a USB cable (i.e. while on the bench) this can be caused by the desktop computer being unable to provide sufficient current to the flight controller - try replacing the USB cable.

If powered from a battery this is a serious problem and the power system (i.e. Power Module, battery, etc) should be carefully checked before flying.

Parameter checks:

Ch7&Ch8 Opt cannot be same: Auxiliary Function Switches are set to the same option which is not permitted because it could lead to confusion.

Check FS_THR_VALUE: the radio failsafe pwm value has been set too close to the throttle channels (i.e. ch3) minimum.

Check ANGLE_MAX: the ANGLE_MAX parameter which controls the vehicle' s maximum lean angle has been set below 10 degrees (i.e. 1000) or above 80 degrees (i.e. 8000).


ACRO_BAL_ROLL/PITCH: the ACRO_BAL_ROLL parameter is higher than the Stabilize Roll P and/or ACRO_BAL_PITCH parameter is higher than the Stabilize Pitch P value. This could lead to the pilot being unable to control the lean angle in ACRO mode because the Acro Trainer stabilization would overpower the pilot' s input.

5.4 ESC Calibration

ESC calibration will vary based on what brand of ESC you are using, so always refer to the documentation for the brand of ESC you are using for specific information (such as tones). “All at once” calibration works well for most ESCs, so it is good idea to attempt it first and if that fails try the “Manual ESC-by-ESC” method.

Please first ensure that the aircraft is connected properly, the calibration is completed, and can be armed successfully, and then remove the aircraft propellers.

1. Push the throttle channel of the transmitter to the highest position. Power on the aircraft, and when you see LED flashing in multiple colors, disconnect the power.
2. Power on again. Do not move the transmitter until you hear the beeping sound.
3. Push the throttle channel of the transmitter to the lowest position. After hearing the beeping sound, push the throttle slightly. If the motor rotates, the calibration is done. If not, please try the above steps again.




5.5 Level Calibration

If the Mission Planner shows the drone not level when you put it horizontal as this picture, You can setup as below to solve the problem.



Under Initial Setup--Mandatory Hardware--select Accel Calibration from the left-side menu--Click Calibrate Level to start the calibration.




5.6 GeoFence

This is a safety protection mechanism that protects the aircraft from flying out of the range you set. When the function is turned on, it will detect whether the GPS is positioned. If there is no positioning, it cannot be enabled.

The setup steps are as follows:

1. Open Full Parameter List.
2. Search for FENCE_ENABLE, change the parameter to 1, and save Params.




Setting parameters introduction:

When setting GeoFence parameters, please search for the following parameters in Full Parameter List and set them.

FENCE_TYPE (GeoFence type):

- Altitude is the height protection, above which the protection action will be performed.
- Circle is circular protection. Take the take-off point as the center of the circle, set the radius to draw a circle, and perform protection actions beyond this range.
- Altitude and Circle is cylindrical row protection. The take-off point is the center of the circle, set the radius, height, and the surrounding cylinder, and perform protection actions beyond this range.

- Polygon is polygon protection. After drawing the polygon on the map in the flight plan, with the maximum point of 84 points, the protection action will be performed if it exceeds this drawing range.
- Altitude and Polygon is height and polygon protection, which adds altitude protection based on polygon protection.
- Circle and Polygon is circle and polygon protection, which adds circle protection on the basis of polygon, so that the limited range is the green area, and when the green area is exceeded, the protection is performed.




FENCE_ACTION:

All: The above 3 types of protection are involved.

Report Only: When the restricted area is exceeded, only Mission Planner message prompts and no other operations are performed.

RTL or Land: Return or land.



FENCE_ALT_MAX (maximum altitude): protection limit maximum flight altitude (10-1000m)

FENCE_RADIUS (maximum radius): Protection limits maximum flight radius (30-10000m)

FENCE_ALT_MIN (minimum altitude): Protection limit minimum flight altitude (-100-100m)

5.7 Onboard OSD

OSD is the abbreviation of On Screen Display in English. It is a kind of screen display technology, which is used to display characters, graphics and images on the display terminal. The status of the aircraft can be displayed in the returned video, and the data of each module can be integrated into the OSD module, and then the OSD module can return the monitored data to the terminal (FPV glasses or screen) and superimpose it on the video transmission image. CrossFlight-CE flight controller integrates an OSD chip. Users do not need to connect an external OSD module. They only need to connect the signal lines corresponding to the image transmission and camera to the OSD port of CrossFlight-CE to use the OSD function.

5.7.1 Setting Introduction

OSD Parameters

OSD_W_RESTVOLT: RESTVOLT warn level. Set level at which RESTVOLT item will flash Range is from 0 to 100.

OSD_CELL_COUNT: Battery cell count. Used for average cell voltage display. -1 disables, 0 uses cell count autodetection for well charged LIPO/LIION batteries at connection, other values manually select cell count used.

OSD_CHAN: Screen switch transmitter channel. This sets the channel used to switch different OSD screens. The value includes 0, 5-16.

OSD_SW_METHOD: Screen switch method. This sets the method used to switch different OSD screens.

0 = switch to next screen if channel value was changed.

1 = select screen based on pwm ranges specified for each screen.

2 = switch to next screen after low to high transition and every 1s while channel value is high.

OSD_OPTIONS: OSD Options. This sets options that change the display, including Decimal pack, Inverted Wind, Inverted AH Roll.

OSD_FONT: OSD Font. This sets which OSD font to use. It is an integer from 0 to the number of fonts available.

OSD_V_OFFSET: OSD vertical offset. Sets vertical offset of the osd inside image.

OSD_H_OFFSET: OSD horizontal offset. Sets horizontal offset of the osd inside image.

OSD_W_RSSI: RSSI warn level. Set level at which RSSI item will flash. The range is from 0 to 99.

OSD_W_NSAT: NSAT warn level. Set level at which NSAT item will flash. The range is from 0 to 30.

OSD_W_BATVOLT: BAT_VOLT warn level. Set level at which BAT_VOLT item will flash. The range is from 0 to 100V.

OSD_UNITS: Display Units. Sets the units to use in displaying items.

0 = Metric (meters, kilometers, meters/second, kilometers/hour) .

1 = Imperial (feet, miles, feet/second, miles/hour) .

2 = SI (meters, kilometers, meters/second) .

3 = Aviation (feet, nautical miles, feet per minute, knots).

OSD_MSG_TIME: Message display duration in seconds. Sets message duration seconds.

OSD_ARM_SCR: Arm screen. Screen to be shown on Arm event. Zero to disable the feature.


OSD_DSARM_SCR: Disarm screen. Screen to be shown on disarm event. Zero to disable the feature.

OSD_FS_SCR: Failsafe screen. Screen to be shown on failsafe event. Zero to disable the feature.

OSD_BTN_DELAY: Button delay. Debounce time in ms for stick commanded parameter navigation.


OSD_W_AVGCELLV: AVGCELLV warn level. Set level at which AVGCELLV item will flash.

OSD_TYPE: 1 means the chip of OSD is MAX7456.



5.7.2 Screen Introduction

The Screen interface is the interface displayed on the user's screen, where the user can independently design the interface layout, display options, etc.



- ① The area is the layout displayed on the screen. Users can freely drag and drop the options inside to customize and adjust the layout of the screen.
- ② The area is the content displayed on the screen. Users can tick the content they need and display it on the screen.
- ③ The area can copy the layout of the current screen or paste the layout of other screens to this screen.
- ④ Write all the current settings in the area.

6. AutoTune


AutoTune attempts to automatically tune the Stabilize P, Rate P and D, and maximum rotational accelerations to provide the highest response without significant overshoot. Copter needs to be

“basically” flyable in AltHold mode before attempting to use AutoTune as the feature needs to be able to “twitch” the copter in the roll and pitch axis.

Position Hold during AutoTune is available in Copter 3.5 (and higher).

Setup before flying

1. Set up one flight mode switch position to be AltHold.
2. Set an Auxiliary Function Switch to Autotune to allow you to turn the auto tuning on/off with the a switch.
3. Remove the camera gimbal or any other parts of the frame that could wobble in flight.
4. Select which combination of axis (roll, pitch, yaw) you wish to tune using the AUTOTUNE_AXES parameter.
5. Set the autotune’ s aggressiveness using the AUTOTUNE_AGGR parameter (0.1=aggressive, 0.075=medium, 0.050=weak), normally start with the default 0.1.
6. For large copters (with props at least 13inch or 33cm diameter) set the Rate Roll and Pitch filters to 10hz (in Copter-3.3 these are RATE_RLL_FILT_HZ and RATE_PIT_FILT_HZ, in Copter-3.4 they are ATC_RAT_RLL_FILT, ATC_RAT_PIT_FILT).
7. It is recommended to enable battery voltage scaling of PID gains.



How to invoke AutoTune?

1. Wait for a calm day and go to a large open area.
2. Ensure the ch7 or ch8 switch is in the LOW position.
3. Take off and put the copter into AltHold mode at a comfortable altitude.
4. Face the vehicle so that it will twitch at 90degrees from the direction the wind is blowing (i.e. if tuning Roll first, point the vehicle into the wind).
5. Set the ch7/ch8 switch to the HIGH position to engage auto tuning:
 - (1) You will see it twitch about 20 degrees left and right for a few minutes, then it will repeat forward and back.
 - (2) Use the roll and pitch stick at any time to reposition the copter if it drifts away (it will use the original PID gains during repositioning and between tests). When you release the sticks, it will continue auto tuning where it left off.
 - (3) Move the ch7/ch8 switch into the LOW position at any time to abandon the autotuning and return to the origin PIDs.

- (4) Make sure that you do not have any trim set on your transmitter or the autotune may not get the signal that the sticks are centered.
6. When the tune completes the copter will change back to the original PID gains.
7. Put the ch7/ch8 switch into the LOW position then back to the HIGH position to test the tuned PID gains.
8. Put the ch7/ch8 switch into the LOW position to fly using the original PID gains.
9. If you are happy with the autotuned PID gains, leave the ch7/ch8 switch in the HIGH position, land and disarm to save the PIDs permanently.

If you DO NOT like the new PIDS, switch ch7/ch8 LOW to return to the original PIDs. The gains will not be saved when you disarm.


If you find after performing an AutoTune that the vehicle feels overly twitchy when flying Stabilize, AltHold or PosHold (but ok in more autonomous modes like Loiter, RTL, Auto) try reducing the RC_FEEL parameter to 0.25. This smooths out the pilot's input. Alternatively try reducing the AUTOTUNE_AGGR parameter (it should always be in the range 0.05 to 0.10) and try again.

If the vehicle feels sloppy after the AutoTune, try increasing the AUTOTUNE_AGGR parameter as high as 0.10 and attempt the autotune again.

7. Parameter Setting

7.1 Parameter Interface Introduction

All of the parameters of CrossFlight-CE can setup in Mission Planner, please do not change the parameters during the flight.



Parameters on the left:

GeoFence: Refer to [Chapter 5.6 GeoFence](#).

Basic Tuning: Set Roll/Pitch sensitivity.

Extended Tuning: Adjust PID, 7 and 8 channel function.

Standard Params: Provide some basic settings such as logs, additional functions, channel functions, etc.

Advanced Params: Provide some advanced function settings such as PID.

Onboard OSD: Refer to [Chapter 5.7 Onboard OSD](#).

MAVFtp: In firmware versions 4.1 and above, integrated FTP (File Transfer Protocol) is implemented, allowing access to the SD card (if there is one) and the internal flash file system through this interface. (It is not recommended to use this system to download logs. Please refer to Chapter 8 to download the log, which is faster).

User Params: Quickly set the functions of the auxiliary channel of the transmitter.

All parameter trees: Related function parameters are displayed closely. After a function is expanded, the function-related parameters are displayed.

Planner: Related settings of Mission Planner.

Parameters on the right:

Load from file: load the files with the parameters have setup already.

Save to file: save the file with the parameters to your computer.

Write Params: write the parameters that have modified to CrossFlight-CE.

Refresh Params: exhibit the newest parameters which have modified no the Mission Planner.

Compare Params: compare the current and the previous parameters.

Load Presaved: load the parameters that Radiolink upgrade the files which design for 210-250 frame racing drone to CrossFlight-CE.

Reset to default: reset all the parameters to default files. Please recalibrate and re-setup all the parameters after reset.

Search: write down the name of parameters you want to setup, much same as the keyboard shortcuts function.

7.2 Parameter Adjustment

All settings of the flight controller can be set or adjusted. You can enter Full Parameter List to search the parameter you want to modify and then modify it. After the modification, please remember to click Write Params on the right.



7.3 Manual Parameter Adjustment

The default parameters of the flight controller may not be applicable for your aircraft and require further manual adjustment. The manual adjustment document is provided below. You can make further fine adjustments according to it. I hope everyone will fly perfectly.

[PID Paramater Adjustment Setup Tutorial](#)

8. Download DataFlash Log

There are two ways to record your flight data. With some exceptions, the two methods record very similar data but in different ways:

Dataflash logs use the CrossFlight-CE onboard dataflash memory, which you can download after the flight. On Copter dataflash logs are created after you first arm the copter.

Telemetry logs (also known as “tlogs”) are recorded by the Mission Planner (or other ground station) when you connect ArduPilot to your computer via a telemetry link.

If you are not yet familiar with the basics of these log files, first review the introductory pages to understand where these logs are stored and how you can download and view the information held within them.



Note: Because the download thread will block the main thread of the flight controller when downloading the log, an internal error will be reported after downloading the log. Please restart the flight controller before the next flight.

Open the log file through the steps below:



Files available for reference: <http://ardupilot.org/copter/index.html>