

Digital 4-Channel Proportional RC System

Instruction Manual



This illustration is for RC4G & RC3S

MENU

1. Introduction and service.....	2
2. Safety guides.....	2
3. Battery recharge notice.....	3
4. Contents and specifications.....	4
5. Receiver installation and binding.....	5
6. Usage method of receiver intergrated with gyro and settings.....	7
7. Schematic for connectors of R4EH-H and R4EH-G.....	7
8. Display when power switch turned on.....	8
9. Language Select "LANGUAGE".....	10
10. Model Select "MODEL".....	10
11. End Point Adjuster "EPA".....	11
12. Steering EXP "STEXP".....	12
13. Steering Speed "STSPD".....	13
14. Throttle EXP "THEXP".....	14
15. Throttle Speed "THSPD".....	16
16. A.B.S. Function "A.B.S".....	18
17. Throttle Acceleration "ACCEL".....	23
18. Idle-Up "IDLUP".....	24
19. Subtrim "SUBTR".....	25
20. Servo Reverse "REV".....	26
21. Steering Dual Rate/Throttle Dual Rate "D/R".....	27
22. ATL Function "ATL".....	28
23. Programmable Mixes "PMIX".....	28
24. Channel 3 Position "AUX".....	31
25. Model name "NAME".....	31
26.Low voltage alarm.....	32
27.Gyro Sensitivity.....	32
28.Fail safe.....	33
29. Reset function "RESET".....	34

Introduction and Service

Thank you for choosing RadioLink RC system, if you are the first time to use this type of products, please read this statement carefully and strictly in accordance with the requirements of operation. You could refer to the Manual if you meet any problems during the operation . Please well keep the manual after use because you might have to use it again next time.

If you found any problems during the operation process, please refer to the manual. If the problem still exists, you could contact our dealers to find out the way to solve it. And you could also log on our website for service:

<Http://www.radiolink.com.cn>

Safety guides

Important Safety Notice:

The following two symbols will appear in this manual (please pay attention to the paragraph with this two symbols labeled):



Prohibition



Testing and confirmation



Do not use in bad weather such as rainy or thundering to assure the safety of you and others.



Forbid to use this product in the crowd and the place against national law!



You need to turn the throttle channel(ch3) and inch switch to the lowest before you use. Then switch on the transmitter, finally connect the receiver.



Before using, please make sure the movements of servo are corresponding with the direction of joystick. If inconsistent, please adjust them before using.



The sequence to shut down is that turn off the receiver power first, and then shut down the transmitter. If the above operations are reverse, it might lead to uncontrolled situation and cause accidents



The transmitter needs to be powered by 4 AA alkaline 5# batteries or Ni-MH batteries. Please check the voltage of batteries before using, as it might lead to uncontrolled situation and accidents when the voltage is lacked. So you must change the battery or recharge them in time.

Battery recharge notice

Recharge steps:

- A. Install the batteries to transmitter with correct directions, and cover it.
- B. Connect the charger to the main connector.
- C. Connect the charger to the transmitter charging port.
- D. Cut off the power supply immediately while recharging completed.


Warning: Don't try to charge to one-off dry batteries, avoiding a fire, explosion or other severe consequence.

If you are using a nickel-cadmium, nickel-metal hydride batteries for recharging, please use our company dedicated charger(optional accessory). If the electrical current is too large and it might lead to overheated and cause a burning accident. Please cut off the power supply immediately after recharging. Please take out the batteries from the transmitter when you are not using it within a period, because the battery might damage the battery connection metal flake, thus cause bad connection.

Above safety notices must be complied strictly, our company will not be responsible for any damage caused by the behaviors forbidden in above notices.

Contents and specifications

Contents and Specifications:



Contents:

1. Antenna
2. Binding key
3. Channel connection pin

Specs:

Size: 51.5*24*15 (mm)



Channel number: 4 channels

Power standard: 4.6-10V

Frequency: 2.4GHz Weight: 5g

Contents:

1. Antenna
2. LCD
3. Menu key
4. Turning wheel
5. Function key A throttle
6. Function key B Direction
7. Function key C the 3rd channel
8. The 3rd/4rd channel VR
9. The 3rd/4rd channel button
10. Recharge connection slot
11. Throttle trigger
12. Simulator port
13. Power switch
14. USB hardware upgrade port



Specs:

Size: 213*117*115.5(mm)

Antenna length: 106mm

Weight: 420g

Channel number: 4 channels

LCD: 128*64 lattice (with backlight)

Power standard: 6VDC (1.5AA*4)

RF power: less than 10dbm

Power extending: JST port 2S~3S

LiPo/LiFePo battery

Modulation: FHSS

Low voltage alert: Yes (lower than 4.6V)

Data resolution: 2048

Frequency: 2.4GHz

RF range: 300meters on ground


Failsafe: in 1 second receiver fail getting signal from TX, the throttle will be 0, servos keep the last status.

* **RC3S standard equipment:**A transmitter and a **R4EH-H receiver.**

* **RC4G standard equipment:**A transmitter and a **R4EH-G receiver.**

Receiver installation and binding

Receiver's connection and installation: (such as some car model)




NOTICE:

1. Confirm battery, switch, servos and etc are connected with receiver right.
2. While installing servos, please keep servo's distance from model body, otherwise the vibration can lead to servo and make servo damaged.
3. After installation of servos, please try to control the servo to full range, if it got stuck or sounded abnormal, you must solve the problem. Even if servo


was not damaged, large circuit occurred.

4. Do not cut off or bind the receiver antenna, and try the best to keep it far away from metal and carbon graphite material.
5. Receiver is made up from precise electronic components, it need to be protected from vibration by packaged with sponge or other shock absorption materials.

Schematic for connectors of R4EH-H



Schematic for connectors of R4EH-G



Code-matching method between transmitter and receiver:

1. Load the battery into transmitter, power on it.
2. Connect the power to the 2nd Channel pin of receiver.
3. Press the binding button on the receiver till LED starts twinkling.
4. LED stops the twinkle, bright light indicates a successful code-matching was completed.

Method of using receiver intergrated with gyro

R4EH-G is intergrated with gyro,it can make cars run stablely, the effect is more obvious when the car is turning. The gyro function can be set "ON"and "OFF"

Description of indicator light:

1.Receiver in normal working condition: Green light on

2.Gyro in working normal condition:Red light on

Attention:The gyro function was set to on by factory.When the receiver is in working condition the red light flashing,the gyro enter a self-examination state. At this time,please keep the receiver in a stable condition.

In normal condition, the direction of cars including forward and backward.The gyro should only work in forward direction. Attention:The vehicle gyro has the phase adjusting function, only when choosing the correct direction,can the gyro really work.

Gyro function settings:

1.Usage method of gyro:Short press the code key for three times(time interval between each time lasts less than 1 second), the red light continuous flashing three times, then the red light into a lasting bright , it shows the gyro in a normal state.

2.The gyro sensitivity: The default is three channel. The VR switch can be used for real-time adjustment when the radio control works,to ensure that the third channel VR control (Factory default)


clockwise, the sensitivity increases, counterclockwise, the sensitivity decreases.

Attention:Sensitivity shuoldn't be set to 0.

3. Gyro usage method in forward and backward direction: When gyro is in working state, pull the remote accelerator to keep the car move forward for a distance, release the accelerator in the premise of not playing the direction key, turn around the car body, if the steering engine doesn't move, then gyro works in backward direction. You need to short press the code button for once (less than 1 second), the right light flashes once, then the gyro works in forward direction.

4. Gyro phase adjustment: When the gyro works in forward direction, turn around the car to observe whether the gyro is correcting wheel. When rotating the car to the left, wheel When to the right, wheel left correction. In this situation, short press code button twice, the phase correction is completed.

Display when power switch turned on



LCD Screen

When you power on the transmitter, LCD screen shows battery voltage, R/C control system name, model name, steering trim, throttle trim, the red light flashes two times

Model Name

The system can store the data for 10 models, model name will show on the LCD when you power on the transmitter. Please make sure the model name the screen displayed is the right what you want. If the model name you chose is not corresponding with your model, the pre-settings should be wrong.

Transmitter battery voltage

In addition to the model#, LCD can show the voltage of battery. When the voltage is lower than 4.6V, it would start the low-voltage alert, it would send out "BeBe..." sounds, till the transmitter is power-off. When you hear the low-voltage alert, you have no more than 4 minutes for controlling your model, please safely stop your model before the uncontrolled situation. Please make sure the battery voltage is higher than this voltage data while radio controlling.


Transmitter function menu setting

When you want to browse or change a setting of transmitter, you should go into function menu setting mode. Under function menu setting mode, you can set up Language Select "LANGUAGE", Model Select "MODEL", End Point Adjuster "EPA", Steering EXP "STEXP", Steering Speed "STSPD", Throttle EXP "THEXP", Throttle Speed "THSPD", A.B.S. Function "A.B.S", Throttle Acceleration "ACCEL", Idle-Up "IDLUP", Subtrim "SUBTR", Servo Reverse "REV", Steering Dual Rate/Second Dual Rate "D/R", ATL Function "ATL", Programmable Mixes "PMIX", Auxiliary Channel 3 and 4 "AUX", Model name "NAME", Reset function "RESET".

Language Select "LANGUAGE"

Both English and Chinese version menu are available for system, which is convenient for Chinese and English-speaking players to personalize function menus.

1. Access the function menu (By pressing “Exit” and “Enter” buttons simultaneously and holding them down for one second), the Language select function will be chosen.
2. Press “Enter” button to get into “LANGUAGE” function interface.
3. Use “Dec(-)” or “Inc(+)” key to select “中文” or “English”, the selected language will be with black shading effect.
4. Press “Enter” button, the desired language is selected, and return to the initial screen automatically.




Model Select "MODEL"

The transmitter can store model memories for ten models. Use this function to call a new model #.

MODEL- Model select function

1. Access the function menu (By pressing “Exit” and “Enter” buttons simultaneously and holding them down for one second), press “Enter” key once, the Model select function will be chosen.
2. Press “Enter” button, the current active model will be blinking.
3. To activate a different model# by pressing “Dec(-)” or “Inc(+)” button until the desired model# blinks.
4. Press “Enter” button, the selected model# stops blinking, now the model# has been selected.
5. Return to the initial screen by pressing “Exit” button twice.



End Point Adjuster "EPA"

Use this when performing left and right steering angle adjustments, throttle high side/brake side operation amount adjustment, and channel 3 servo up side/down side operation amount adjustment during linkage.

Correct the maximum steering angle and left and right steering angles when there is a difference in the turning radius due to the characteristics, etc. of the vehicle.

Setting item (channel and direction)

ST-LFT: Steering (left side)

ST-RGT: Steering (right side)

TH-FWD: Throttle (forward)


TH-BRK: Throttle (brake side)

3C-LFT: 3rd channel (left side)

3C-RGT: 3rd channel (right side)

4C-UP: 4th channel (up side)

4C-DWN: 4th channel (down side)



Steering EPA

ST-LFT:0~120

ST-RGT:0~120

Initial value:120

Throttle EPA

TH-FWD:0~120

TH-BRK:0~120

Initial value : 120



Aux Servo EPA

3C- LFT:0~120

3C-RGT:0~120

Initial value :120

Aux Servo EPA

4C-UP:0~120

4C-DWN:0~120

Initial value :120

End point adjustment

1. Access the function menu (By pressing "Exit" and "Enter" buttons simultaneously and holding them down for one second),press "Inc(+)" button twice to chose EAP function.

2.Press "Enter" button to get into EPA function interface, use "Dec(-)" or "Inc(+)"

button to select the desired setting item , press “Enter” key the initial value of your selected setting item will blink, then you can press “Dec(-)” or “Inc(+)” button to adjust the value of your selected setting item.

(Note: In the interface of adjusting the value, return to the initial value "120" by pressing “Dec(-)” and “Inc(+)” buttons simultaneously for about 1 second.)

3. Press “Enter” button, the adjusted value of your selected setting item stops blinking, now the value of your selected setting item has been set.

4. Return to the initial screen by pressing “Exit” button twice.

Steering EXP "STEXP"

This function is used to change the sensitivity of the steering servo around the neutral and both ends position. It has no effect on the maximum servo travel.

Adjust the sensitivity of direction wheel both in neutral position and ends


Setup item

RATE: Steering EXP rate

Adjustment range

-100~0~+100

Initial value :0



0~-100 Sensitivity around neutral position is low,getting higher when approaching ends.

0 Sensitivity around the neutral and ends position is equal

0~+100 Sensitivity around neutral position is high,getting lower when approaching ends

Steering operation curve adjustment

1.Access the function menu (By pressing “Exit” and “Enter” buttons simultaneously and holding them down for one second), press “Inc(+)” button three times to chose EAP function.

2.Press “Enter” button to get into STEXP function interface, press “Enter”key and the initial value of the rate will blink, then you can press “Dec(-)” or “Inc(+)” button to adjust the value and the curve of the rate shown in the figure will change correspondingly.

(Note: In the interface of adjusting the value, return to the initial value "0" by pressing “Dec(-)” and “Inc(+)” buttons simultaneously for about 1 second.)

3. Press “Enter” button, the adjusted value of the rate stops blinking, now the value of the rate has been set.
4. Return to the initial screen by pressing “Exit” button twice.

Note: the Vertical cursor shown in the figure moves in step with steering wheel operation.

Steering Speed "STSPD"

Quick steering operation will cause momentary understeering, loss of speed, or spinning. This function is effective in such cases.

Setup item


TURN:TURN direction

RETURN:RETURN direction

Adjustment range

1~100% (each direction)

At 100%, there is no delay



Steering servo delay

1. Access the function menu (By pressing “Exit” and “Enter” buttons simultaneously and holding them down for one second), press “Inc(+)” button four times to choose STSPD function.
2. Press “Enter” button to get into STSPD function interface, press “Dec(-)” or “Inc(+)” button to select setup item, then press “Enter” key and the initial value of selected setup item will blink.
3. Use “Dec(-)” or “Inc(+)” button to adjust the value of the selected setup item. (Note In the interface of adjusting the value, return to the initial value "100" by pressing “Dec(-)” and “Inc(+)” buttons simultaneously for about 1 second.)

4. Press “Enter” button, the adjusted value of the selected setup item stops blinking, now the value of the selected setup item has been set.
5. Return to the initial screen by pressing “Exit” button twice.

Throttle EXP "THEXP"

This function makes the throttle high side and brake side direction servo operation quicker or milder. It has no effect on the servo maximum operation amount. For the high side, selection from among three kinds of curves (CRV/VTR/EXP) is also possible.

The curve can be divided into :Five dots throttle curve adjustment,Single point adjustment.

Exponential curve adjustment,Braking index curve adjustment. To elevation point, we can select(Exponential curve/Single point curve/Five points curve).

Curve point adjustment(select five points 1-5)

- 1.Press"Enter" button,The curve point value start flashing,then press"Dec(-)"and"Inc(+)" button to adjust the starting value.
- 2.Press "Enter" button ,starting value stop flashing,adjustment is completed.
- 3.Press "Exit" button for two times,back to the initial interface.


Throttle curve adjustment Adjustment method for CRV curve

Setup items

Mode: INT/ACT

TG.P: 20~80

RATE: -100~0 ~ +100




1. Enter the function menu and use “Dec(-)” or “Inc(+)” button to access THEXP function. Select “FWD-CRV” function.

2. Press “Dec(-)” or “Inc(+)” button to select curve points 1~5 for curve point adjustment that you want, from the graph you will clearly see the changes you have made.

Adjustment method for VTR curve

Adjustment range

RATE: 0 ~+100



1.Enter the function menu and use “Dec(-)” or “Inc(+)” button to access THEXP function. Select

“FWD-VTR” function.

2. Press “Dec(-)” or “Inc(+)” button to select RATE for forward side adjustment that you want, when the “MODE” value is “INT” the VTR will not work, only the “MODE” value set to “ACT” the VTR function is available. From the graph you will clearly see the changes you have made on TG.P and RATE.

Adjustment method for EXP curve

Setup items


MODE: EXP turn on or turn off

RATE: EXP rate

Adjustment range

MODEL: INT/ACT

RATE: -100 ~ 0 ~ +100



1. Enter the function menu and use “Dec(-)” or “Inc(+)” button to access THEXP function, then select the “FWD-EXP” function.

2. Press “Dec(-)” or “Inc(+)” button to select RATE for adjustment, set the most comfortable value you want. From the graph you will clearly see the changes you have made on the EXP RATE, also move the trigger to check the throttle status.

Adjustment method for BRK-EXP curve

Setup items

RATE: BRK-EXP rate

Adjustment range


RATE: -100 ~ 0 ~ +100

0~-100 flat braking

0 uniform braking

0~+100 sensitive braking

Brake side adjustment (select BRK)



(1). Press “Enter” key, the current BRK value will blink, use “Inc(+)” button to adjust the + side when you want to quicker the rise and use “Dec(-)” button to adjust the-

side when you want to make the rise milder.

(Note: In the interface of adjusting the value, return to the initial value "0" by pressing "Dec(-)" and "Inc(+)" buttons simultaneously for about 1 second.)

(2). Press "Enter" button, the adjusted BRK value stops blinking, now the BRK value has been set.

3. When ending setting, return to the initial screen by pressing "Exit" button twice.

Throttle Speed "THSPD"

Throttle servo delay

Sudden throttle trigger operation on a slippery road only causes the wheels to spin and the vehicle cannot accelerate smoothly. Setting the throttle speed function reduces wasteful battery consumption while at the same time permitting smooth, enjoyable operation.

Operation

Throttle servo (amp) operation is delayed so that the drive wheels will not spin even if the throttle trigger is operated more than necessary. This delay function is not performed when the throttle trigger is returned and at brake operation.

OFF, Speed 1 or speed 2 can be selected.

OFF means shut down the throttle speed function

Adjustment method for SPEED 1

Setup items


MODE: Speed type selection

ALL: Speed adjustment

Adjustment range

1~100 (each direction)

At 100, there is no delay



1. Enter the function menu and use "Dec(-)" or "Inc(+)" button to access THSPD

function.

2. Press “Enter” button to get into THSPD function interface.

3.If initial MODE setup item is SPEED 1, { if initial MODE setup item is SPEED 2 or OFF, you need to select SPEED 1 by pressing “Dec(-)” or “Inc(+)” button to select MODE setup item , then press “Enter” key, SPEED 2 or OFF will blink, press “Dec(-)” or “Inc(+)” button, when the blinking SPEED 2 or OFF change to blinking SPEED 1, press “Enter” key, SPEED 1 will stop blink, now SPEED 1 is selected}, press “Dec(-)” or “Inc(+)” button to select ALL set up item, then press “Enter” key, the initial value will blink, use “Dec(-)” or “Inc(+)” button to adjust the delay of the entire throttle forward side range.

(Note: In the interface of adjusting the value, return to the initial value "100" by pressing “Dec(-)” and “Inc(+)” buttons simultaneously for about 1 second.)

Press “Enter” button, the adjusted value stops blinking, now the value has been set.

4. When ending setting, return to the initial screen by pressing “Exit” button twice.

Adjustment method for SPEED 2


Setup items

MODE: Speed type selection

LOW: Low side range speed adjustment

HIGH: High side range speed adjustment

TGP1: Low and medium speed switching point



Adjustment range

LOW: 1~100

HIGH: 1~100

At 100, there is no delay

TGP1: 1~100

1. Enter the function menu and use “Dec(-)” or “Inc(+)” button to access THSPD function.

2. Press “Enter” button to get into THSPD function interface.

3.If initial MODE setup item is SPEED 2,{ if initial MODE setup item is SPEED 1, you need to select SPEED 2 by pressing “Dec(-)” or “Inc(+)” button to select MODE setup item , then press “Enter” key, SPEED 1 or OFF will blink, press “Dec(-)” or “Inc(+)” button,when the blinking SPEED 1 or OFF change to blinking SPEED 2,press “Enter” key,SPEED 2 will stop blinking, now SPEED 2 is selected}, press “Dec(-)” or “Inc(+)” button to select "LOW" or "HIGH" delay adjustment or “TGP1” Speed switching point adjustment.

4.Press “Enter” key to confirm "LOW" or "HIGH" or “TGP1” setup item, and the value of your selected setup item will blink. Use “Dec(-)” or “Inc(+)” button to adjust the value.

(Note: In the interface of adjusting the value, return to the initial value (the initial value of LOW and HIGH is “100”, the initial value of TGP1 is “30”) by pressing “Dec(-)” and “Inc(+)” buttons simultaneously for about 1 second.)

Press “Enter” button, the adjusted value stops blinking, now your selected value has been set.

5.When ending setting, return to the initial screen by pressing “Exit” button twice.

A.B.S. Function "A.B.S"

Pulse brake

When the brakes are applied while cornering with a 4 Wheel Drive or other type of vehicle, understeer may occur. The generation of understeer can be eliminated and corners can be smoothly cleared by using this function.


Operation

- When the brakes are applied, the throttle servo will pulse intermittently. This will have the same effect as pumping the brakes in a full size car.
- The brake return amount, pulse cycle, and brake duty can be adjusted.
- The region over which the ABS is effective can be set according to the steering operation. (Mixing function)

Setup items

ABP: Brake return amount

DLY: Delay amount
CYC: Cycle speed
TGP: Operation point
DTY: Cycle duty ratio
STM: Steering mixing



-ABP : Amount of brake returnSets the rate at which the ser-vo returns versus trigger operation for brake release. When set to 0%, the ABS function is not performed. When set to 50%, the servo returns 50% (1/2) of the trigger operation amount and when set to 100%, the servo returns to the neutral position.


-DLY : DelaySets the delay from brake operation to ABS operation. When set to 0%, the ABS function is activated without any delay. AT 50%, the ABS function is activated after a delay of approximately 0.7 second and at 100%, the ABS function is activated after a delay of approximately 1.4 seconds.

-CYC: Pulse speedSets the pulse speed (cycle). The smaller the set value, the faster the pulse cycle.

- TGP: Trigger pointSets the trigger point at which the ABS function begins to operate at brake operation.

- DTY: Cycle duty ratioSets the proportion of the time the brakes are applied and the time the brakes are re-released by pulse operation. The ratio can be set to +3 ~ 0 ~ -3 in 7 steps.

- STM: Steering mixingSets ABS operation ON/OFF according to the steering operation range.



A.B.S function adjustment

Enter the function menu and use “Dec(-)” or “Inc(+)” button to access A.B.S function, then press “Enter” button to get into A.B.S function interface.

1.(Brake return amount adjustment)

Select the setting item "ABP" by pressing "Dec(-)" or "Inc(+)" button, then press "Enter" key and the initial value of "ABP" will blink. Use "Dec(-)" or "Inc(+)" button to adjust the return amount.

(Note: In the interface of adjusting the value, return to the initial value "50" by pressing "Dec(-)" and "Inc(+)" buttons simultaneously for about 1 second.)

Press "Enter" button, the adjusted value stops blinking, now the value has been set.

"0": No return

"50": Return to the 50% position of the brake operation amount

"100": Return to the neutral position.

Brake return amount (ABP)

0 ~ 50 ~ 100

Initial value; 50

- Brake return amount (ABP) is influenced by the "EXP" rate on the brake side.

2. (Delay amount setup)

Select the setting item "DLY" by pressing "Dec(-)" or "Inc(+)" button, then press "Enter" key and the initial value of "DLY" will blink. Use "Dec(-)" or "Inc(+)" button to adjust the delay amount.

(Note: In the interface of adjusting the value, return to the initial value "0" by pressing "Dec(-)" and "Inc(+)" buttons simultaneously for about 1 second.)

Press "Enter" button, the adjusted value stops blinking, now the value has been set.

"0": A.B.S. function performed without any delay

"50": A.B.S function performed after an approximate 0.7 sec delay

"100": A.B.S. function performed after an approximate 1.7 secs delay

Delay amount (DLY)

0 ~ 100

Initial value; 0

3. (Pulse speed adjustment)

Select setting item "CYC" by pressing "Dec(-)" or "Inc(+)" button, then press "Enter" key and the initial value of "CYC" will blink. Use "Dec(-)" or "Inc(+)" button to adjust the pulse speed (cycle).

(Note: In the interface of adjusting the value, return to the initial value "5" by pressing "Dec(-)" and "Inc(+)" buttons simultaneously for about 1 second.)

Press "Enter" button, the adjusted value stops blinking, now the value has been set.

- The smaller the set value, the faster the pulse speed.

Cycle speed (CYC)

0 ~ 30

Initial value; 5

4. (Operation point setup)

Select setting item "TGP" by pressing "Dec(-)" or "Inc(+)" button, then press "Enter" key and the initial value of "TGP" will blink. Use "Dec(-)" or "Inc(+)" button to adjust the operation point.

(Note: In the interface of adjusting the value, return to the initial value "30" by pressing "Dec(-)" and "Inc(+)" buttons simultaneously for about 1 second.)

Press "Enter" button, the adjusted value stops blinking, now the value has been set.

- Sets the throttle trigger position at which the A.B.S. function is performed. The number is the % display with the full brake position made 100.

Operation point (TGP)

0 ~ 100

Initial value; 30

5. (Cycle duty ratio setup)

Select setting item "DTY" by pressing "Dec(-)" or "Inc(+)" button, then press "Enter" key and the initial value of "DTY" will blink. Use "Dec(-)" or "Inc(+)" button to adjust the duty ratio.

(Note: In the interface of adjusting the value, return to the initial value"0"by pressing "Dec(-)" and "Inc(+)" buttons simultaneously for about 1 second.)

Press "Enter" button, the adjusted value stops blinking, now the value has been set.

"-3":Brake application time becomes shortest. (Brakes lock with difficulty)

"+3":Brake application time becomes longest (Brakes lock easily)

(Remark) For low grip, set at the - side and for high grip, set at the + side.

Duty ratio (DTY)

-3 ~ 0 ~ +3

Initial value; 0


6. (Steering mixing setup)

Select setting item "STM" by pressing "Dec(-)" or "Inc(+)" button, then press "Enter" key and the initial value of "STM" will blink. Use "Dec(-)" or "Inc(+)" button to adjust the steering mixing range.

(Note: In the interface of adjusting the value, return to the initial value"OFF" by pressing "Dec(-)" and "Inc(+)" buttons simultaneously for about 1 second.)

Press "Enter" button, the adjusted value stops blinking, now the value has been set.

-Sets the range within which the A.B.S. function is performed relative to steering wheel operation.



Steering operation

Steering mixing (STM)

OFF, N10 ~ N100, E10 ~ E100

Initial value; OFF

When steering mixing is set and steering operation enters the set range, "*" is displayed in front of the number. When mixing is OFF, the A.B.S function can operate over the entire steering range.

7. When ending setting, return to the initial screen by pressing “Exit” button twice.

Throttle Acceleration "ACCEL"


Function which adjusts the movement characteristic from the throttle neutral position

The servo will jump to the input position at its maximum possible speed. Unlike exponential, which adjusts the whole throttle movement into a curve, throttle acceleration simply "jumps" away from neutral and then leaves the remaining response linear.

Setup item

FWRD:Forward side acceleration amount

BRAK:Brake side acceleration amount



Throttle acceleration adjustment

Enter the function menu and use “Dec(-)” or “Inc(+)” button to access ACCEL function, then press “Enter” button to get into ACCEL function interface.

1.(Forward acceleration amount adjustment)

Press “Dec(-)” or “Inc(+)” button to select “FWRD”,press“Enter”key to confirm and the initial value of “FWRD” will blink,then use “Dec(-)”or“Inc(+)” button adjust the acceleration amount.

(Note: In the interface of adjusting the value,return to the initial value "0"by pressing “Dec(-)” and “Inc(+)” buttons simultaneously for about 1 second.)

Press“Enter” button, the adjusted value stops blinking, now the value has been set.

"0":No acceleration

"100":Maximum acceleration(Approximately 1/2 of the forward side steering angle)

Forward acceleration amount(FWRD)

0~100

Initial value: 0

2. (Brake side acceleration amount adjustment)

Press “Dec(-)” or “Inc(+)” button to select “BRAK”, press “Enter” key to confirm and the initial value of “BRAK” will blink, then use “Dec(-)” or “Inc(+)” button adjust the acceleration amount.

(Note: In the interface of adjusting the value, return to the initial value "0" by pressing “Dec(-)” and “Inc(+)” buttons simultaneously for about 1 second.)

Press “Enter” button, the adjusted value stops blinking, now the value has been set.

"0": No acceleration

"100": Maximum acceleration (Brake side maximum steering angle)

Brake side acceleration amount(BRAK)

0~100

Initial value: 0

3. When ending setting, return to the initial screen by pressing “Exit” button twice.

Idle-Up "IDLUP"

Idle up at engine start

Use this function to improve the starting characteristics of the engine by raising the idling speed when starting the engine of a gas powered car.


Idle-Up rate (RATE)

D50% ~ D1%, 0%, U1% ~ U50%

Initial value: 0%

"D": Brake side

"U": Forward side



1. Enter the function menu and use “Dec(-)” or “Inc(+)” button to access IDLUP function.

2. Press “Enter” button to get into IDLUP function interface.

3. Press “Enter” key, and the initial value of RATE will blink. Use “Dec(-)” or “Inc(+)” button to adjust the value.

(Note: In the interface of adjusting the value, return to the initial value "0%" by pressing “Dec(-)” and “Inc(+)” buttons simultaneously for about 1 second.)

Press “Enter” button, the adjusted value stops blinking, now the value has been set.

4. When ending setting, return to the initial screen by pressing “Exit” button twice.

Subtrim "SUBTR"

Servo center position fine adjustment

Use this function to adjust the neutral position of the steering, throttle and channel 3 servos.

Channel

ST:Steering

TH:Throttle

CH3:Channel3

CH4:Channel4

Subtrim


ST:L100~R100

TH:B100~F100

CH3:-100~+100

CH4:-100~+100

Initial value : 0



1. Enter the function menu and use “Dec(-)” or “Inc(+)” button to access SUBTR function.

2. Press “Enter” button to get into SUBTR function interface.

3. Use “Dec(-)” or “Inc(+)” button to select ST channel, press “Enter” key, and the initial value of ST will blink. Use “Dec(-)” or “Inc(+)” button to adjust the center. (Note: In the interface of adjusting the value, return to the initial value "0" by pressing “Dec(-)” and “Inc(+)” buttons simultaneously for about 1 second.)
4. Press “Enter” key, the adjusted value stops blinking, now the center of ST has been adjusted.
5. TH channel and CH3 channel can be set similarly.
6. When ending setting, return to the initial screen by pressing “Exit” button twice.

Servo Reverse "REV"

Servo operation reversing

This function reverses the direction of operation of the servos related to transmitter steering, throttle, channel 4 and channel 3 operation.


Channel

ST: Steering

TH: Throttle

CH3: Channel3

CH4: Channel4



1. Enter the function menu and use “Dec(-)” or “Inc(+)” button to access REV function.
2. Press “Enter” button to get into REV function interface.
3. Use “Dec(-)” or “Inc(+)” button to select ST channel, press “Enter” key, and the symbol “▶” will blink.
4. Press “Enter” key, the symbol “▶” stops blinking. Use “Dec(-)” or “Inc(+)” button to reverse the ST servo operation direction.
5. TH channel, CH3 and CH4 channel can be set similarly.
6. When ending setting, return to the initial screen by pressing “Exit” button twice.

Steering Dual Rate/Throttle Dual Rate "D/R"

Dual rate

The steering left and right servo travels are adjusted simultaneously. When you want to increase the servo travel, adjust the + side. When you want to decrease the servo travel, adjust the – side.

Setup Item

Steering D/R

RATE

Throttle D/R

RATE



Steering D/R rate (RATE)

0~100%

Initial value: 100

Throttle D/R rate (Throttle D/R RATE)

0~100%

Initial value: 100

1. Enter the function menu and use “Dec(-)” or “Inc(+)” button to access D/R function.
2. Press “Enter” button to get into D/R function interface.
3. Use “Dec(-)” or “Inc(+)” button to select Steering D/R RATE, press “Enter” key, and the initial value of Steering D/R RATE will blink. Use “Dec(-)” or “Inc(+)” button to make adjustments.
(Note: In the interface of adjusting the value, return to the initial value "100" by pressing “Dec(-)” and “Inc(+)” buttons simultaneously for about 1 second.)
4. Press “Enter” key, the adjusted value stops blinking, now the steering D/R RATE has been set.
5. Throttle D/R RATE can be set similarly.
6. When ending setting, return to the initial screen by pressing “Exit” button twice.

Brake side adjustment

This function decreases the set value when the braking effect is strong and increases the set value when the braking effect is weak.

Setup Item

RATE: Brake amount

Brake amount (RATE)

0~100%

Initial value: 100%

1. Enter the function menu and use “Dec(-)” or “Inc(+)” button to access ATL function.


2. Press “Enter” button to get into ATL function interface.

3. Press “Enter” key, and the initial value of RATE will blink. Use “Dec(-)” or “Inc(+)” button to adjust the value.

(Note: In the interface of adjusting the value, return to the initial value "100%" by pressing “Dec(-)” and “Inc(+)” buttons simultaneously for about 1 second.)

Press “Enter” button, the adjusted value stops blinking, now the value has been set.

4. When ending setting, return to the initial screen by pressing “Exit” button twice.



Programmable Mixes "PMIX"

Programmable mixes between arbitrary channels

These functions allow you to apply mixing between the steering, throttle, and channel 3 channels.


Setup items

LEFT: Mixing rate (Left side)

RGHT: Mixing rate (Right side)

MST: Master channel

SLV: Slave channel



MXMD:Mix mode

Enter the function menu and use “Dec(-)” or “Inc(+)” button to access PMIX function, then press “Enter” button to get into PMIX function interface.

1.(Master channel)

Channel selection (MST)

ST, TH, CH3

Initial value: ST

Select setup item "MST" by pressing “Dec(-)” or “Inc(+)” button, press “Enter” button, the initial master channel will blink. Use “Dec(-)” or “Inc(+)” button to select the master channel you wish to adjust, press “Enter” button, the blinking master channel you selected will stop blinking.

2.(Slave channel)

Channel selection (SLV)

ST, TH, CH3

Initial value:ST

Select setup item "SLV" by pressing “Dec(-)” or “Inc(+)” button, press “Enter” button, the initial slave channel will blink. Use “Dec(-)” or “Inc(+)” button to select the slave channel you wish to adjust, press “Enter” button, the blinking slave channel you selected will stop blinking.

3. (Left, forward or up side mixing amount adjustment)

Mixing amount

-100~0~+100

Select the setting item "LEFT", "FWRD", or "UP"(These setup items are different depend on the master channel. ST: "LEFT"; TH: "FWRD"; CH3:"UP") by pressing “Dec(-)” or “Inc(+)” button . press “Enter” key, the initial value of "LEFT", "FWRD", or "UP" will blink, Use “Dec(-)” or “Inc(+)” button to adjust the left, forward, or up side mixing amount.

(Note: In the interface of adjusting the value, return to the initial value "0" by pressing

“Dec(-)” and “Inc(+)” buttons simultaneously for about 1 second.)

Press “Enter” key, the adjusted value stops blinking, the selected mixing amount has been adjusted.

4. (Right, brake or down side mixing amount adjustment)

Mixing amount

-100~0~+100

Select the setting item "RGHT", "BRAK", or "DOWN" (These setup items are different depend on the master channel. ST:"RGHT"; TH:"BRAK"; CH3:"DOWN") by pressing “Dec(-)” or “Inc(+)” button. Press “Enter” key, the initial value of "RGHT", "BRAK", or "DOWN" will blink, Use “Dec(-)” or “Inc(+)” button to adjust the right, brake, or down side mixing amount.

(Note: In the interface of adjusting the value, return to the initial value "0" by pressing “Dec(-)” and “Inc(+)” buttons simultaneously for about 1 second.)

Press “Enter” key, the adjusted value stops blinking, the selected mixing amount has been adjusted.

5. (Mixing mode setup)

Mixing mode (MXMD)

OFF, MIX

Initial value: OFF

Select setup item "MXMD" by pressing “Dec(-)” or “Inc(+)” button, press “Enter” button, the initial mixing mode “OFF” will blink. Press “Dec(-)” or “Inc(+)” button to switch “OFF” to “MIX”, press “Enter” button, the blinking “MIX” will stop blinking.

"OFF": Mixing proportional to master channel operation.

"MIX": Mixing by master channel another function considered.

6. When ending setting, return to the initial screen by pressing “Exit” button twice.

Channel 3 and Channel 4 Position "AUX"

The channel 3 and channel 4 servo position can be set from the transmitter. When CH3 is assigned to the 3rd channel key, this setting is linked to the key. When CH3 and CH4 is not assigned to the 3rd channel key, it can be set with this screen. You can also set the CH3 and CH4 as VR at the same time, or SW.

Channel 3 position (POSI)

-100~+100

Channel 4 position (POSI)

-100~+100

Initial value: 0


1. Enter the function menu and use “Dec(-)” or “Inc(+)” button to access AUX function.

2. Press “Enter” button to get into CH3 or CH4 function interface.

3. Use “Dec(-)” or “Inc(+)” button to select Channel setup item.

Use “Dec(-)” or “Inc(+)” button to select POSI, press “Enter” key and the value will blink, use “Dec(-)” or “Inc(+)” button to select “VR” or “SW”.

Press “Enter” button, the adjusted value stops blinking, now the value has been set.



Model name "NAME"


RC3S/RC4G stores model memories for five models. Each model memory can be named separately according to user's requirement.

Factory default name: MODEL5

1. Enter the function menu and use “Dec(-)” or “Inc(+)” button to access NAME function.

2. Press “Enter” button to get into NAME function interface the first character of current name will blink, and the blinking character can be reset. The common use characters appear at the bottom of the screen, use

“Dec(-)” or “Inc(+)” button to choose the character you desired. Press “Enter” button again, the next character of current name will blink. Reset other characters of current name in same manner.



3. After accomplishment of naming, all characters of current name will stop blinking, the new name will be stored automatically.
4. When ending setting, return to the initial screen by pressing "Exit" button twice. (the new setting model name will appear on the initial screen)

Low battery voltage alarm

The transmitter's low voltage alarm is adjustable, it depends on what kind of battery, the 4.6V is for 1s Lithium battery. Lower volt may cause the battery over discharge and damage the battery. So you can set transmitter's warning voltage when you use different battery.

There are four options you can choose:

Li2S-7.2V

Li3-10.8V

Ni4S-4.6V

CUSTOM: adjustable 4.6V to 12.0V.




The car will be out of control if the battery runs out, please immediately stop running when the alarm starting to ring.

Gyro Sensitivity

This function is available to set gyro sensitivity and VR mixing ON or OFF. When is MIX is set OFF, gyro is disabled; When the MIX is set ON, you can adjust gyro sensitivity STD or CH3. STD is adjusted on screen and CH3 can be adjusted by VR button. CH3 is defaulted by VR switch.

In normal mode (STD), range of sensitivity is 0-100

1. enter the menu, use Dec(-) and Inc(+) to select options for Gyro sensitivity
2. press the key button Enter to enter sub-menu Gyro Sensitivity
3. press Enter again, the initial value will start flashing, then use Dec (-) and Inc (+) to change the value.



4. Press the button key Enter, the value stops flashing, the setting is finished now.
5. "Mode" and "Rate" can also be set by the same step.
6. Press button key Exit to be back to initial screen.

Remind: the above mentioned function GYRO SENSITIVITY is for RC4G only and cannot use for RC3S

Fail safe

This function is set by servo, throttle, CH3 and CH4.

Option:

SERVO

THROTTLE

CH3

CH4

RANGE:


Servo: L100~R100

Throttle: B100~F100

CH3: -100~+100

CH4: -100~+100

Initial value: 0




1. Enter the menu, use Dec (-) and Inc (+) to select options to set.
2. Press the button key Enter to enter menu.
3. Use Dec (-) and Inc (+) to select SERVO, then press Enter. Now the initial value of SERVO will start flashing, use handle to change the value.
4. Press the button key Enter, the value stops flashing, now the value of SERVO is set.
5. THROTTLE is to set by the trigger;
CH3 is to set by VR controller;
CH4 is to set by the button switch.
6. Press Exit two times to back to initial screen.

Reset function "RESET"

REST- Data reset function:

All the data for any model memory can be reset to original factory defaults. Often this function is done to get a "fresh start" and clear the memory before inputting new model settings.

1. Enter the function menu and use "Dec(-)" or "Inc(+)" button to access RESET function.
2. Press "Enter" button to get into RESET function interface, the symbol "YES" will blink.



Be sure to reset

Press "Enter" key, the symbol "YES" will stop blinking, and return to the initial screen. Now the model data is reset to the initial setting that is the default value set at the factory.

Not to reset

Press "Dec(-)" or "Inc(+)" button, the symbol "YES" will stop blinking and the symbol "NO" will blink, press "Enter" key, the symbol "NO" will stop blinking, return to the initial screen by pressing "Exit" button twice.

Or you can press "Exit" button twice to quit resetting directly.

CAUTION: Resetting the current model memory will permanently erase ALL programming information for that model. The data cannot be recovered. Do not reset the model unless you are certain you want to clear-out that memory and start from scratch.

Thank you again for using our product, we hope it can bring you happiness!